

# Sewing Pattern — Blouse 4200

Recommendations on fabric: blouse fabric of natural or mixed fibers / satin

You will also need: fusing; 10 buttons

If the pattern has double contour the seam allowances are included.

If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out and cutting details.

Seam allowance: on hem – 1.5 cm, other seams – 1 cm.

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



#### **CUTTING**:

## Main fabric:

- 1. Back part 2 details
- 2. Upper front part 2 details
- 3. Lower side front part 2 details
- 4. Lower central front part 2 details
- 5. Panel 2 details
- 6. Frill 4 details
- 7. Collar 2 details
- 8. Stand-up part of collar 2 details
- 9. Sleeve 2 details
- 10. Cuff 2 details

#### Fusing:

- 1. Collar 1 detail
- 2. Stand-up part of collar 1 detail
- 3. Panel 2 details
- 4. Cuff 2 details

# **INSTRUCTIONS**:

- 1. Apply fusing to panels, cuffs, top collar and inner stand-up part of collar.
- 2. Fold top collar with lower right sides together. Overstitch ends and outer edge of collar. Cut seams. Turn collar out, straighten and press. Fold stand-up part details right sides together, insert ready collar between them, level notches and sew, overstitching ends of stand-up part at the same time. Start and finish the stitch exactly near marked line of stand-up part connection seam. Turn ready collar out and press.
- 3. Sew details of lower front part. Serge and press towards center of front part.



- 4. Stitch loosely on lower edge of top front part between notches and gather ruffles. Sew top and bottom front part. Serge and press downwards.
- 5.Fold frills right sides together and overstitch outer side. Slash seam allowances on rounded parts, turn detail onto right side, serge, press. Make plaits and fasten on top edge according to marked lines. Put frill on front part and fix along neckline and middle seam.
- 6. Press panels in half lengthwise wrong sides together. Stitch outer edge of panel to front part. Press the seam towards panel side. Turn inner edge of the panel inwards and topstitch in connecting seam.
- 7. Sew darts on back part. Press darts to middle seam. Sew middle seam of back part. Serge and press.
- 8. Sew shoulder and side seams. Serge and press to back part.
- 9. Sew upper stand-up part of collar with collar in the neckline, turn open edge of lower stand-up part and topstitch in upper stand-up part connection seam.
- 10. Serge edges of sleeve. Sew edge of sleeve from marker upwards, press seam allowances apart. Sew sleeve in armhole. Serge and press to the sleeve. Fold cuff in half lengthwise right sides together and sew side edges. Start and finish the stitch exactly near marked connection line. Turn detail onto right side, press. Stitch outer side of cuff to the sleeve, turn seam allowance of inner side of cuff inside and topstitch into outer cuff connecting seam.
- 11. Serge hem of the garment, press onto wrong side and topstitch.
- 12. Serge buttonholes on right front part, sew buttons on left one. Make buttonholes and sew buttons on stand-up part of collar and cuffs.

## **TECHNICAL DRAWING:**

