

Sewing Pattern — Dress 5217

Recommendations on fabric: elastic fabric of 150 cm width.

You will also need: zipper.

If the pattern has double contour the seam allowances are included.

If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out and cutting details.

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



CUTTING:

Fabric:

1. Back center part – 2 pieces
2. Back side right part – 1 pieces
3. Back side left part – 1 pieces
4. Front side left part – 1 pieces
5. Outer stand-up collar – 1 pieces
6. Inner stand-up collar – 1 pieces
7. Front center part – 1 pieces
8. Front side right part – 1 pieces
9. Draping – 1 pieces
10. Sleeve – 2 pieces

INSTRUCTIONS:

1. Sew front right relieve seam.
2. Fold allowance of upper /lower edges of draping to wrong side and sew. Make pleats according to marks. Apply draping wrong side on front central part's right side and tack along edges.
3. Sew back central seam downwards from the mark. Sew back relieve seams and front left relieve, shoulder edges and side edges. Neaten seams.

4. Make pleats into upper stand-up collar. Fold outer stand-up collar with inner one and overstretch along upper edge. Sew lower edges of outer stand-up collar to garment neckline right sides together. Fold lower edge of inner stand-up collar and topstitch it on joining seam.
5. Press closure allowance into prong side. Sew the zipper in.
6. Make pleats along sleeve caps. Cut allowance along sleeve cap to 1 cm. Sew sleeve seams. Sew sleeves into armholes. Fold hems allowances into wrong side and sew.
7. Press slit allowances of front left part into wrong side. Press all hem allowances into wrong side. Sew by hand.

TECHNICAL DRAWING:

