

Sewing Pattern — Dress 5210

Recommendations on fabric: silk of 150 cm width.

You will also need: 1 zipper.

If the pattern has double contour the seam allowances are included.

If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out and cutting details.

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



CUTTING:

Fabric:

1. Strap – 2 pieces
2. Armhole edging – 2 pieces
3. Neckline edging – 1 piece
4. Middle back part – 2 pieces
5. Side back part – 2 pieces
6. Side front part – 2 pieces
7. Middle front part – 2 pieces
8. Flounce – 1 piece

INSTRUCTIONS:

1. Sew front darts.
2. Process short and curved long edges of flounce as follows: fold the edge under at 1 cm and topstitch at 1 mm from bending. Cut the allowance at 1 mm from stitch, fold it under again (as narrow as possible) and topstitch along the seam.
3. Sew front middle seam inserting the flounce between details, with its wide side up. Slash allowance. Sew front/back relieve seams as well as back middle seam between the mark and the hem.

4. Press closure allowance to wrong side. Sew the zipper under slit edges with its teeth hidden.
5. Press slit allowance to wrong side and topstitch.
6. Press edgings and straps along the center. Unfold the stripe, turn edges to wrong side towards bending and bending the stripe along this bending line. Cut upper part allowance to 0.5 cm. Insert neckline edge into ready edging and topstitch at 1 mm from lower bending. Do the same for upper edge of back part and armholes.
7. Topstitch straps. Sew front ends under front corners. Try the dress, adjust straps length and sew back ends to back part.
8. Follow dress hem under at 1 cm.

TECHNICAL DRAWING:

