

Sewing Pattern — Blouse 5124

Recommendations on fabric: viscose poplin of 150 cm width

You will also need: fusing; 4 buttons.

If the pattern has double contour the seam allowances are included.

If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out and cutting details.

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



CUTTING:

Fabric:

1. Front part (one-piece with front band) – 2 details
2. Back part – 1 folded detail
3. Back neckline facing – 1 folded detail
4. Piping – 2 details

Fusing:

1. Back neckline facing – 1 folded piece
2. Front band – 2 pieces

INSTRUCTIONS:

1. Apply the fusing to wrong side of back neckline facing and front band.
2. Sew front/back darts, press dart depths towards center; press bust darts upwards.
3. Sew side edges of back neckline facing to front band short edges, right sides together. Press seam allowance apart. Tack facing and front bands to garment neckline along upper edges; then stitch. Turn facing and front band to wrong side, press and topstitch close to edge on right side.
4. Sew side edges and shoulder edges. Press seam allowances apart.
5. Overstitch armhole edge: cut armhole allowance. Press the piping along the center. Pin folded piping to armhole edge and stitch at 0.75 cm. Press the piping upwards, fold piping ends under. Turn the piping over seam allowance, tack above joining seam and topstitch it on right side along joining seam.
6. Press hem allowance to wrong side, fold it under and topstitch at 0.75 cm.
7. Make buttonholes into right front part and sew buttons on left one.

TECHNICAL DRAWING:

