

Sewing Pattern — Jacket 5082

Recommendations on fabric: double-sided organza of 140 cm width

You will also need: 3 large plastic snaps, fusible interfacing

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: hem 3 cm; 1 cm on all other seams

Attention! First of all, please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to take into account pieces to be duplicated or cut on a fold.

When sewing the garment, pay attention to notches. They must match up with corresponding pieces.



CUTTING:

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Darts: The fold of the dart is always pressed toward the center of your garment, or down toward the hem.

Fabric:

1. Center front – cut 2
2. Side front – cut 2
3. Back – cut 2
4. Upper sleeve – cut 2
5. Elbow – cut 2
6. Collar – cut 2
7. Front band facing – cut 2
8. Back neck facing – cut 1
9. Pocket – cut 2

Fusible interfacing: front band facing, back neck facing, back hem

INSTRUCTIONS:

1. Apply interfacing to facings and back hem.
2. Sew center back seam, serge seam and press toward left. Sew darts and press toward center.

3. Sew side front to center fronts. Serge and press seam allowances toward side. Sew darts. Cut seam allowances to 0.75 cm width and press upwards.
4. Fold pocket's self-facing onto right side, and sew to side edges. Turn the facing onto wrong side, fold pocket outer edges onto wrong side. Topstitch the pocket along upper edge. Pin the pocket on front and topstitch along the edge.
5. Sew side/shoulder seams, serge and press toward back.
6. Sew the collar along outer edges; baste open lengthwise edges into neckline. Sew back neck facing to front band facings. Serge outer edges of facing. Pin facing to garment and sew to lower edges of front, lapels, and neckline, catching the collar. Turn facing and hem allowance onto wrong side. Press edges. Serge lower edge of garment. Tack inner edges of facing and front band-facing to seam/hem allowances. Hand stitch hem.
7. Sew sleeve seams. Serge lower edge of sleeves, press sleeve hems onto wrong side, and hand stitch.
8. Make a gathering stitch along sleeve cap for ease. Sew sleeves in, matching marks and easing along sleeve caps.
9. Sew snaps on front so that stitches are invisible on front right side.

TECHNICAL DRAWING:

