

## Sewing Pattern — Jacket 5079

Recommendations on fabric:  
wool of 150 cm width

You will also need: lining of 140 cm width; fusing of 0.90 m and 140 cm width; 4 buttons of 20 mm diameter, shoulder pads.

If the pattern has double contour the seam allowances are included.

If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out and cutting details.

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



### **CUTTING:**

Fabric:

1. Back part – 2 pieces
2. Front part – 2 pieces
3. Upper sleeve – 2 pieces
4. Lower sleeve – 2 pieces
5. Collar – 2 pieces
6. Flap – 2 pieces
7. Frame – 4 pieces
8. Front band – 2 pieces
9. Back neckline facing – 1 piece

Lining:

Cut front parts excluding front bands' widths. Cut lower sleeves with seam allowance only. Cut back part excluding the width of back neckline facing (folded in the middle). Warp goes parallel to fabric's bending that results into free-fit pleat of nearly 1 cm depth.

10. Sacking – 4 pieces
11. Flap – 2 pieces

Fusing: apply the fusing additionally to wrong side of back hem.

**NB:** if your dress is of check fabric, pin details on fabric taking into account how checks coincide along seams.

## **INSTRUCTIONS:**

1. Apply the fusing to wrong side of front bands, inner collar, flaps and back neckline facing.
  2. Stitch front darts and press them apart, cut allowances along pocket entrances. Tack pocket entrances with crossed stitches coinciding entrances strictly.
  3. Stitch side seams.
  4. Cut slit "frame" pockets with two facings and flaps into front part: stitch neatly one fabric/one lining flaps along side/lower edges. Topstitch along edges. Apply fusing stripe of 4 cm width on wrong side of front part (above pocket marking). Lay two pocket facings on front part right sides together; pin along pocket entrance marking and stitch (lengthwise edges of facings must coincide with middle line of pocket marking). Cut front part between stitches, diagonally at stitch ends. Do not cut through facing! Press slit edges contrariwise entrances. Turn facings to wrong side through slit to make a neat frame, than tack (facing bendings meet at centers of pocket entrances.) Topstitch along joining seams. Turn small triangles at slit ends into wrong side and stitch strictly to facings between upper stitch ends and lower stitch ends, stitch together at facing side seam's side. Lay flaps' open edges between facings and stitch along seams joining upper facings. Stitch sackings on wrong side to allowances of seams joining flaps/allowances of seams joining lower facings. Cut sackings, adjust them and stitch them together.
  5. Stitch back darts and press them apart. Stitch middle back seam. Stitch shoulder seams.
  6. Stitch inner collar into neckline; stitch shoulder seams of back facing and front bands, stitch outer collar into facing neckline and front bands; press allowances apart, slash at rounding.
  7. Lay outer collar joint with front bands on the garment (right sides together), then overstitch edgings and the collar as well as armholes; turn right side out and press; sew allowances of outer collar's edge on neckline allowance. On right side: turn edging, collar and armholes right side out and tack.
  8. Apply the fusing to wrong side of sleeves' hems. Stitch upper sleeves to sleeves' elbow part; press allowances apart and turn sleeves right side out. Press sleeve hem allowances into wrong side.
  9. Ease sleeve cap slightly between marks and pull the cord till sleeve cap coincides to armhole. Moist the fabric and iron pleats. Pin sleeves to the garment coinciding marks. Stitch sleeves to garment at sleeve side. Sew shoulder pads.
  10. Make free-fit pleat and fix it under neckline and few centimeters above garment hem. Stitch darts into lining details. Stitch lining details in the same way as fabrics ones excluding a segment of 20 cm length into one sleeve's elbow seam. Lay the lining on the garment right sides together coinciding along middle back line and along shoulder seams. Overstitch the garment with lining along front bands and neckline. Make a lapping pleat into hem and stitch the lining to hem edge. Turn the garment right side out through sleeve segment, then stitch segment's edges together.
- Make buttonholes into right front part and sew buttons on left one.

**TECHNICAL DRAWING:**

