

Sewing Pattern — Dress 5070

Recommended fabric: wool/wool blend -150 cm width and of 2.70-2.75-2.80m.

You will also need: 0.90 m of fusible interfacing - 140 cm width; 5 buttons - 20 mm diameter.

If the pattern has a double line around it, the seam allowances are included.

Seam allowance: 4 cm on hem; 1 cm on all other seams.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to take into account pieces to be duplicated or cut on a fold.

When sewing the garment, pay attention to notches, they must coincide.



CUTTING:

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Darts: The fold of the dart is always pressed toward the center of your garment, or down toward the hem.

Main fabric:

1. Center back – cut 2
2. Side back – cut 2
3. Front – cut 2
4. Lower side front – cut 2
5. Collar – cut 2
6. Front facing – cut 2
7. Pocket flap – cut 4
8. Pocket frame – cut 4
9. Back neck facing – cut 1 on fold

Lining:

10. Pocket Sacking – cut 4

Interfacing: outer collar, 2 flaps, front facings, back neck facing

Note: if your dress is check/plaid fabric, be sure to match pattern design along the seam edges of pieces that will be sewn together.

INSTRUCTIONS:

1. Apply interfacing on wrong side of front facings, outer collar, flaps and back neck facing.
2. Sew front darts and press them apart. Mark pocket entry at center front/lower side front.
3. Constructing the welt pocket: sew pocket flaps along side/lower edges. Clip corners, and turn right side out. Topstitch along edges. Apply a 4 cm wide fusible interfacing strip to wrong side of front (above pocket marking). Lay pocket facings on front right sides together; pin along pocket entrance marking and stitch (lengthwise edges of facings must coincide with middle line of pocket marking). Cut front part between stitches, snipping diagonally toward end of stitching. Do not cut through facing! Turn facings to wrong side through slit to make a neat frame, then tack (facing's fold meets at centers of pocket entrances.) Topstitch along joining seams. Turn small triangle at slit ends onto wrong side, and stitch strictly to facings between upper stitch ends and lower stitch ends.
Sew together from facing seam's side. Lay flap's open edge between facings and stitch along seams joining upper facings. Sew sackings on wrong side to allowances of seams joining flaps/allowances of seams joining lower facings. There are many methods for sewing the welt pocket. Here is a great video tutorial for a [welt pocket with flap](#).
4. Sew shoulder seams. Serge and press toward back.
5. Sew inner collar to neckline; sew shoulder seams of back neck facing and front facings. Sew outer collar to facing, press seam allowance apart, clip into curves.
6. Pin outer collar with front facings/back facing on the garment, right sides together, then sew seams of collar as well as armholes. Turn right side out and press. Sew outer collar's edge on neckline allowance. On right side: turn seam allowance under, collar and armholes right side out, tack, then press. Topstitch, collars and armholes.
7. Sew center front seam horizontally between front facings' bottom and garment's hem.
8. Sew side seams of dress and facing in one continuous stitch.
9. Serge lower edge of dress. Turn onto wrong side, and topstitch.
10. Make buttonholes on right front, sew buttons on left one.

TECHNICAL DRAWING:

