

Sewing Pattern — Dress 2027

Recommended fabric: lightweight dress fabrics of natural or mixed fibers (chiffon, crepe-chiffon).

You will also need: facing, lining; blind zipper; fusible interfacing; 1 button.

If the pattern has a double line around it, the seam allowances are included.

Seam allowance: all seams - 1 cm; on hem – 3 cm.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to take into account pieces to be duplicated or cut on a fold.

When sewing the garment, pay attention to notches, they must coincide.



CUTTING:

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Darts: The fold of the dart is always pressed toward the center of your garment, or down toward the hem.

Main fabric:

1. Back - cut 2
2. Side front - cut 2
3. Center front – cut 1
4. Decorative front neck/facing- cut 2

Lining:

1. Back - cut 2
2. Side front -cut 2
3. Center front – cut 1

Fusible interfacing: decorative neck piece– cut 1

INSTRUCTIONS:

1. Apply fusible interfacing to decorative neck piece.
2. Sew darts on back, press toward center. Sew side fronts to center front, clip into curves and press seam open.
3. Serge center back edges separately. Sew center back seam from zipper notch to hem. Press seam apart including opening for zipper. Sew in zipper.
4. Sew side seams, press seams apart.
5. Sew lining pieces similar to main fabric. Pin lining to the garment, right sides together, and sew upper edge of back and front armhole edge. Turn garment onto right side, press. Baste lining to main fabric along center front edge. Turn center back seam allowance of lining under, and sew to zipper tape.
6. Pin decorative neck piece to facing, right sides together, and sew inner edge, sewing short sides as well. Trim seam allowances, understitch, and press right side out. Serge lower edge of facing. Sew decorative neck piece to front as marked. Topstitch lower facing into connecting seam, press.
7. Serge lower edge of garment and lower edge of lining. Turn each onto wrong side and topstitch. Lining should be 2 cm shorter than main fabric.
8. Make buttonhole on decorative neck and sew a button.

TECHNICAL DRAWING: