

## Sewing Pattern — Sweatshirt 6102

Recommendations on fabric: jersey or fleece;

You will also need: 1 separable zipper (depending on yoke's length); elastic cord for hood; 2 holders for cord.

If the pattern has double contour the seam allowances are included.

If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out and cutting details.

Seam allowance: 1 cm for all seams, 2.5 cm for garment/sleeve hems and for hood front edge.

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to take into account pieces to be duplicated or cut on a fold.

When sewing the garment, pay attention to notches, they must coincide.

### **CUTTING:**

(On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.)

#### Main fabric:

1. Front part – 1 piece
2. Back part – 1 piece
3. Sleeve – 2 pieces
4. Front yoke – 2 pieces
5. Hood – 2 pieces
6. Hood center part – 1 piece
7. Front band – 2 pieces
8. Sacking – 4 pieces
9. Back facing – 1 piece

**ADVICE:** to prevent seam from stiffing, sew details with special (zig zag) stitch. To prevent hem from stiffing neaten it with overlock and then stitch using double needle. Do the same for all edges which must stay elastic.

The above is not for industrial manufacturing.

### **INSTRUCTIONS:**

1. Lay one part of zipper on edging right sides together (directing teeth from edging). Overstitch edgings with front bands inserting the zipper.
2. Stitch sackings to pocket entrance's edge. Slash allowance and press sackings. Stitch sackings together.



3. Stitch the yoke with front band to front part. Stitch shoulder edges. Stitch sleeves into open armholes. Topstitch seams joining sleeves along armholes. Stitch side seams and sleeve seams. Stitch hood details together. Neaten hood loops. Fold hood front edge's allowance under and topstitch it. Stitch the hood into neckline. Stitch back facing to front band. Overstitch the neckline. Topstitch the seam joining the zipper. Topstitch pockets and make fixes.
4. Press garment/sleeve hems under. Topstitch garment/sleeve hems.
5. Topstitch facing on back part according to marks.
6. Press ready garment.
7. Pull the cord into hood.

**TECHNICAL DRAWING:**

