

Sewing Pattern — Dress 7199

Note: Dress is for a girl of 116-152 cm height (bust 56-76 cm).

Recommendations on fabric: stretch-velvet

You will also need: trim tape of 2 – 2.5 cm wide (length is shown on upper front pattern piece), satin ribbon of 0.5 cm wide.

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam allowance: all seams - 1 cm.

Attention! First of all, please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to take into account pieces to be duplicated or cut on a fold.

When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

CUTTING:

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Main fabric:

1. Upper back – 1 detail
3. Upper front – 2 details
4. Skirt gore – 8 details

Advice:

Knitted fabric details are sewn together with special elastic, narrow zig-zag stitch, or can be serged using an overlock machine. Seam allowance on hem is stitched with double needle to save stretchiness.

INSTRUCTIONS:

1. Sew shoulder seams. Serge and press seam allowances toward back. Put trim tape right side to neckline edge and stitch. Turn seam allowance onto wrong side, closing neckline edge and topstitch from right side. Put upper right front on upper left part and fix near lower edge.
2. Sew 4 front gores. Serge seam allowances. Press center seam onto left side, other seams - toward center. Process lower back the same way. Put upper and lower fronts right sides together and sew. Serge seam allowance and press downwards. Put upper and lower backs right sides together and sew. Serge seam allowance and press downwards.



3. Sew and serge side edges of the dress. Press apart the seam. Serge armhole edge, turn inside and topstitch.
4. Sew tape into ring overlapping ends. Put trim tape right side to hem edge and stitch. Turn seam allowance onto wrong side, closing hem edge and topstitch from right side.
5. Cut belt loops from satin ribbon. Stitch them on side seams and center seam of back. Run ribbon through belt loops and tie.

TECHNICAL DRAWING:

