

## Sewing Pattern — Sweatshirt 7101

Recommendations on fabric: soft wool

You will also need: fusible interfacing; 1 separating zip; decorative cord (see approximate length along the hood/garment hem on patterns)

If the pattern has a double line around it, the seam allowances are included.

**Note:** By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

SEAM ALLOWANCE: 1 cm for all seams, 3 cm for garment/sleeve hems/pocket entrance/hood's outer edge

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to take into account pieces to be duplicated or cut on a fold.

When sewing the garment, pay attention to notches, they must match up with corresponding pieces.



### **CUTTING:**

Fabric:

1. Front part – 2 pieces
2. Back part – 1 piece
3. Pocket – 2 pieces
4. Back yoke – 1 piece
5. Front band – 2 pieces
6. Back neckline facing – 1 piece
7. Sleeve – 2 pieces
8. Hood side – 2 pieces
9. Hood center – 1 piece

Interfacing: front band, back neckline facing, flaps.

### **INSTRUCTIONS:**

1. Apply the interfacing to wrong side of front band, back neckline facing, pocket entrance.
2. Stitch hood sides to hood center and neaten seams. Neaten hood loops. Fold hood allowance into wrong side, fold it under and topstitch on the hood.
3. Neaten the pocket along the contour and pocket entrance and press it according to the pattern. Fold pocket entrance's allowance into wrong side and topstitch it at 2.5 cm from the edge. Lay the

pocket on front part and topstitch according to marks.

4. Lay front parts right sides together, adjust edges and measure front edgings' length. Stitch the zipper to edges.

5. Stitch the yoke to back part. Press seam allowances towards the yoke and topstitch along the seam.

6. Stitch side/shoulder seams, neaten them and press backwards.

7. Stitch back neckline facing to front bands. Neaten outer edges of front bands/facings. Lay front bands on front parts right sides together and overstretch along front edgings and neckline inserting the hood (overstretch at front side).

8. Neaten buttonholes. Turn front edgings into right side, press seams.

9. Stitch sleeve edges and neaten them. Press sleeve seams. Fold seam allowance into wrong side and press first at 1 cm and then at 2 cm. Topstitch allowances' pressed seams on sleeves. Stitch sleeves into armholes according to notches.

10. Make topstitching along the zipper at 0.5 cm from it. Press garment's hem first at 1 cm and then at 2 cm. Fold it into wrong side and topstitch. Pull the cord into hood's holes and into the hem.

#### **TECHNICAL DRAWING:**

