

Sewing Pattern — Jacket 7099

Recommendations on fabric: denim

You will also need: fusible interfacing; 5 studs

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

SEAM ALLOWANCE: 1 cm for all seams, 2 cm for garment/sleeve hems.

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to take into account pieces to be duplicated or cut on a fold.

When sewing the garment, pay attention to notches, they must match up with corresponding pieces.



CUTTING:

Fabric:

1. Back yoke – 1 piece
2. Center back part – 1 piece
3. Lower back part – 1 piece
4. Side back part – 2 pieces
5. Center front part – 2 pieces
6. Lower front part – 2 pieces
7. Side front part – 2 pieces
8. Upper pocket – 2 pieces
9. Upper flap – 4 pieces
10. Lower pocket – 2 pieces
11. Lower flap – 4 pieces
12. Stand-up collar – 2 pieces
13. Elbow part – 2 pieces
14. Front sleeve – 2 pieces
15. Cuff – 2 pieces

Interfacing: outer stand-up collar, flaps.

INSTRUCTIONS:

1. Cut fusing for one-piece front band.

2. Apply the fusing to wrong side of flaps, front band and outer stand-up collar.
3. Lay flaps right sides together and overstitch them. Cut rounded corners' allowances and turn flaps right side out. Topstitch flap's outer contour at 0.5 cm from the edge. Neaten flap's upper edge.
4. Press inverted pleat into the pocket. Topstitch pleat's bends at 0.1 cm distance. Fix the pleat with a stitch (0.5 cm from upper/lower edges of the pocket). Neaten the pocket along the contour and press it corresponding to the pattern. Topstitch upper edge on the pocket.
5. Lay upper collar in inner stand-up and overstitch them along outer contour. Cut allowances of stand-up's rounded corners and turn the stand-up right side out. Press the stand-up.
6. Stitch darts into side front part. Press it toward the center. Topstitch darts at 0.1 cm distance.
7. Stitch front/back relieves. Neaten front/back relieves. Topstitch at 0.5 cm from relieve joining seams.
8. Stitch lower pieces to front/back parts. Neaten seams, then press them. Topstitch at 0.5 cm from joining seams.
9. Topstitch pockets on front parts along contour at 0.2 cm from pockets' edges. Topstitch flaps on tacking. Fold flaps into right side and topstitch them at 0.5 cm from seams.
10. Stitch the yoke to back part. Neaten the seam and press it upwards. Topstitch at 0.5 cm from joining seam.
11. Stitch shoulder seams and neaten them. Press shoulder seams backwards.
12. Neaten front bands' edges. Fold one-piece front band into right side and overstitch upper corner up to the mark. Slash the neckline at mark's level, 0.1-0.2 cm before front band.
13. Stitch outer stand-up into the neckline, fold inner stand-up's open edge under and topstitch along the seam joining outer stand-up. Topstitch the stand-up collar.
14. Neaten elbow edge. Stitch the elbow seam up to slit notch. Press elbow seam apart and topstitch slit's allowance on the sleeve at 0.5 cm distance. Topstitch at 0.5 cm from elbow seam.
15. Stitch sleeves into open armholes according to notches. Stitch jacket's side edge and sleeve's lower edge with one stitch, then neaten and press backwards. Make a pleat into sleeve hem and fix it with a stitch at 0.5 cm from the edge.
16. Fold cuffs along the center and overstitch along outer contour leaving the edge free.
17. Stitch upper cuff to sleeve hem. Overstitch cuff's corners. Fold inner cuff's upper edge under at 1 c, and topstitch along the seam joining outer cuff. Topstitch along cuff's contour.
18. Set studs into front parts and into cuffs.

TECHNICAL DRAWING:

