

Sewing Pattern — Top 7039

Recommendations on fabric: viscose poplin

You will also need: fusible interfacing; 3 buttons.

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to take into account pieces to be duplicated or cut on a fold.

Darts: The fold of the dart is always pressed toward the center of your garment, or down toward the hem.

When sewing the garment, pay attention to notches, they must match up with corresponding pieces.



CUTTING:

Fabric:

1. Collar – 2 folded pieces
2. Back part – 1 folded piece
3. Lower front part – 1 folded piece
4. Front yoke – 1 folded piece
5. Back neckline facing – 1 folded piece
6. Front facing – 2 pieces
7. Back sleeve – 2 pieces
8. Front sleeve – 2 pieces

Interfacing: back neckline facing, outer collar .

INSTRUCTIONS:

1. Apply the interfacing to wrong side of back neckline facing, outer collar. Reinforce also closure lower segment with interfacing.
2. Press one-piece plackets of front facing to right side and overstretch the projection which is placket upper segment between bend and marking line. Slash neckline edge neat stitch end stopping 1 mm before stitch; turn the placket right side out and press. Lay facings on front part right sides together and topstitch along long edges. Cut placket allowance and make triangle slash at its end. Turn plackets to wrong side, adjust them and reinforce with double stitch along base.

3. Sew shoulder/side seams to slit marks.
4. Lay collar details right sides together and topstitch along ends and fly parts. Turn right side out and press.
5. Sew shoulder seams of front facings and back neckline. Turn front bands to right sides, lay it on garment right sides together, insert the collar and stitch. Turn facing and front band to wrong side and press.
6. Sew sleeve lower/upper edges to notch mark. Press allowances apart.
Sew sleeves into armholes.
7. Press garment/sleeve hem to wrong side, fold them under and topstitch. Topstitch slit edges at 1 mm from bends.
8. Make buttonholes into right placket and sew buttons on left one.

TECHNICAL DRAWING:

