

Sewing Pattern — Coat 7020

Recommendations on fabric: quilted water-proof checked fabric

You will also need: cotton piping of 410 cm length and 1 cm width; 3 button loops

If the pattern has double contour the seam allowances are included.

Seam allowances are NOT included by default and need to be added when laying out and cutting details if your pattern has single contour.

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide



CUTTING:

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Fabric:

1. Front part – 2 pieces
2. Back part – 1 folded piece
3. Back yoke – 2 pieces
4. Hood/front yoke – 2 pieces
5. Pocket – 2 pieces
6. Sleeve – 2 pieces
7. Flap – 2 pieces

INSTRUCTIONS:

1. Stitch the yoke to back part. Remove the warmer at allowances, press allowances toward the yoke, fold the edge under and stitch along edges.
2. Remove the warmer along short and one long edges of the flap. Fold allowances double and stitch with double stitch.
3. Remove the warmer along pocket's upper edge. Fold all layers under, insert flap's open edge between them and stitch along the edge.

4. Remove the warmer along pocket open edges. Fold edges under and stitch the pocket to front part with double stitch.
5. Stitch hood details right sides together. Press allowances rightward. Cut half width of lower allowances, fold upper allowance under and stitch on the garment along the edge with double decorative stitch.
6. Stitch the hood/yoke to front part in the same way as on back part.
7. Do the same for shoulder seams and stitch the hood into back neckline. Before do this, slash hood allowances at shoulder seams.
8. Stitch sleeves into armholes and trim allowances with the piping.
9. Stitch side/sleeve seams with one stitch, trim allowances with the piping.
10. Remove the warmer along front edgings/hood edges, fold all layers under and stitch with double stitch.
11. Remove the warmer along the hem, fold double into wrong side and stitch along the edge. Do the same for sleeve hems.
12. Stitch button loops as marked.

TECHNICAL DRAWING:

