

Sewing Pattern — Short coat 4318

Recommendations on fabric: natural or mixed fabric suitable for coats

You will also need: interfacing; 5 buttons for hidden panel; lining; shoulder pads

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam allowances: all seams - 1 cm, on hem of the garment - 3 cm; on sides of off-set welt — 2 cm

Attention! First of all, please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to take into account pieces to be duplicated or cut on a fold.

When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

CUTTING:

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Darts: The fold of the dart is always pressed toward the center of your garment, or down toward the hem.

Fabric:

1. Back – cut 1 on fold
2. Front –cut 2
3. Button-stand facing– cut 2
4. Collar – cut 2
5. Off-set welt – cut 2
6. Back neck facing – cut 1
7. Front cuff — cut 2
8. Back cuff —cut 2
9. Corded ribbon —cut 2
10. Belt loop — cut 1



Lining:

1. Back – cut 1
2. Front – cut 2
3. Big pocket bag – cut 2
4. Small pocket bag – cut 2
5. Facing for hidden button panel – cut 2
6. Front band closure — cut 2

ATTENTION: use main fabric pattern pieces to cut out back and front lining details excluding the width of back neckline facing and the width of button stand facing.

Interfacing:

1. Button-stand facings, back neck facing, hidden button panel facing – cut 2

INSTRUCTIONS:

1. Apply interfacing to button-stand facings, back neck facing and hidden button panel from lining.
2. Sew bust darts on front. Press toward center.
3. Mark pocket location. Apply corded ribbon to pocket opening. Press off-set welt in half lengthwise wrong sides together. Topstitch small pocket bag on inner side of off-set welt. Stitch off- set welt to front along lower line of pocket marking. Stitch big pocket bag to front along top line of pocket marking. End the stitches near short marking lines. Cut pocket opening along line. Snip diagonally at 1-1.5 cm from the end of pocket up to end of stitch line. Turn off-set welt and big pocket bag wrong side out through the given slit. Attach ends of pocket from the wrong side with double back stitch on corners' base line. Sew edges of pocket bags. Here is an great video tutorial for making [the single welt pocket](#).
4. Fold cuff in half, wrong sides together, and press. Sew outer side of cuff to sleeve. Press seam apart.
5. Sew shoulder seams, together with sleeve and cuff edge. Press seam apart.
6. Making hidden button panel. Attention! Top buttonhole on front is not included in hidden button panel! Mark closure slit with three lines on right side of right button-stand facing: first line is parallel to button-stand line at 1.5 cm off the edge of button-stand when ready; second and third lines limit the the length of the closure. Lay interfaced facing onto right side of button-stand, right side downwards and directed from the edge of button-stand, matching edge of facing and marked line. Sew at 0.5 cm from the marked edge along the closure slit up to lines that limit closure length. Put second closure facing edge-to-edge to the stitch that connects first facing and sew at 0.5 cm. Check you connected facings from the wrong side (stitches must be parallel). Cut along center. Make diagonal snips 1-1.5 cm from the end of the closure slit up to end of stitching. Turn facings wrong side out through given slit, shaping a frame from interfaced facing, that is equal to width between stitches. Make a fastening stitch into the facing connecting seam. Press second facing towards inner edge of button-stand facing and make a fastening stitch at 0.1 cm from the facing connecting seam. Mark and finish buttonholes. Buttonholes are made on button-stand facing together with interfaced facing. Straighten and fasten ends of closure from the wrong side with double back stitch on corners' base line. Sew together edges of facings. Make bar tacks between each pair of buttonholes, length of bar tack is equal to the width of frame. Press button-stand facing.
7. Sew and press apart shoulder edges of back neckline facing and button-stand facings.
8. Sew outer collar into the neckline of back and front. Press the seam apart. Sew inner collar to

button-stands and neck facing. Press seam apart.

9. Pin closure lining to button-stand and inner collar and sew section between markers. Clip seam allowances near markers and press lining onto wrong side. Pin closure lining to button-stand and outer collar and sew section between markers. Clip seam allowances near markers and press lining onto wrong side. Make buttonholes on button-stand facing and on inner collar.

10. Pin button-stand facing onto front, right sides together, and sew: right button-stand from hem up to marker, stop the stitch, and from marker upwards, on collar and on left button-stand. Sew from side of the front. Sew lower edges of button-stand facings to the front exactly along marked hem-line, leaving 1.5 cm to inner edge of button-stand facing. Trim lower corners of button-stand facing. Turn button-stands right side out, straighten seams. Turn front back, and topstitch lining of button-stand closure and facing along marked horizontal lines.

11. Serge one long edge on belt loop. Press unfinished edge inside, closing from above with finished edge. Sew a double stitch, along the belt loop. Cut belt loop into 2 pieces.

12. Sew side seams, inserting belt loops. Trim seam allowances and press seam apart.

13. Sew side seams on lining details, leaving a slit. Sew lining to inner edges of button-stand facings and back neck facing. Sew lining to lower edge. Sew lining to inner edge of cuff. Press seam onto lining. Fasten together outer and inner sides of cuff along connection line.

14. Sew a decorative stitch or topstitch on right front, continuing it on collar, fastening hidden button panel (stitch marking is shown on front pattern piece, second line from button-stand).

15. Sew buttons on left front.

Wear the coat with wide belt.

TECHNICAL DRAWING:

