

## Sewing Pattern — Beach Coverup 4130

Recommendations on fabric: natural or mixed light fabrics.

You will also need: lace trim of 1.0 – 1.5 cm wide  
( approximate length is shown on patterns).

If the pattern has double contour the seam allowances are included.

Seam allowances are NOT included by default and need to be added when laying out and cutting details if your pattern has single contour.

Seam allowances: 1 cm.

**Attention!** First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



### **CUTTING:**

(On the pattern pieces, “beam” means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.)

Main fabric:

1. Back – cut 1
2. Front – cut 1
3. Casing – cut 2
4. Back neck facing – cut 1
5. Front neck facing – cut 1

### **INSTRUCTIONS:**

1. Sew shoulder seams. Serge and press seam allowances towards back.
2. Sew shoulder seams of the facings, press seam allowances apart. Serge outer edge.
3. Sew the facing to the neckline, right sides together, Trim seam and clip into curves. Press seam allowance toward facing and understitch. Turn, press, and topstitch.
4. Serge side seams, press toward wrong side and topstitch. Serge bottom edge. Topstitch the trim along bottom edges.
5. Make two buttonholes for the tie according to marks. Press short edges of the casing under and topstitch. Press under longitudinal edges of the casing. Place casing along marked line on the wrong side of the front and back and topstitch at 0.1 cm off the fold.

6. Cut the tie the needed length (approximately waist circumference + 1.0 m), width is 4 cm. Press the tie in half lengthwise, wrong sides together. Then unfold and press longitudinal edges to marked line. Turn short seam allowances inside and topstitch the tie at 0.1 cm off the edge. Run the tie through casings.

**TECHNICAL DRAWING:**

