

Straight Dress - Sewing Pattern #4445

Recommendations on fabric: natural/mixed fabric suitable for dresses.

You will also need: fusible interfacing.

Seam allowances: seam allowance for hem of garment — 2 cm, other seams - 1 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Back - cut 2
2. Front — cut 1 on fold
3. Sleeve — cut 2
4. Back stand collar — cut 2
5. Front collar — cut 2
6. Cuff — cut 2

Fusible interfacing:

1. Back stand collar — cut 1
2. Front collar — cut 1

INSTRUCTIONS:

1. Apply fusible interfacing to stand collars.
2. Sew darts on back, press bulk towards center. Sew center back seam, press towards left, serge.
3. Make and baste pleats on front neckline.
4. Sew shoulder seams, press seam allowances towards back and serge.
5. Sew stand collar pieces together by two. Pin together outer and inner stand collars right sides together and sew upper edges. Clip into curves. Turn right side out stand collar at **лицевую сторону**, straighten, press. Make and baste a box pleat.
6. Sew sleeve to front and to back, clipping into corners. Clip into curves, press onto sleeve and serge.
7. Sew lower edge of sleeve and side edges at the same time, serge and press.
8. Sew cuff into a ring, press seam apart. Fold cuff in half lengthwise and press right side out. Pin cuff onto right side of sleeve and sew. Serge, turn cuff right side out.
9. Serge lower edge of garment, press onto wrong side and topstitch.

TECHNICAL DRAWING:

