

## Sewing Pattern — Coat 4081

Recommendations on fabric: natural or mixed costume fabric.

You will also need: fusing; 1 decorative button; 4 buttons for hidden closure; lining; shoulder pads; sleeve heads.

If the pattern has double contour the seam allowances are included.

Seam allowances are NOT included by default and need to be added when laying out and cutting details if your pattern has single contour.

<u>Seam allowances:</u> all seams - 1 cm, on hem of the garment and of sleeve - 3.5 cm.

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



### **CUTTING:**

### Main fabric:

- 1. Back 1 detail
- 2. Front 2 details
- 3. Button stand 2 details
- 4. Upper sleeve part 2 details
- 5. Lower sleeve part 2 details
- 6. Back neckline facing 1 detail

### Lining:

- 1. Back 1 detail
- 2. Front 2 details
- 3. Upper sleeve part 2 details
- 4. Lower sleeve part 2 details
- 5. Hidden closure 2 details

ATTENTION: details of back and front parts are cut except for the width of back part neckline facing and button stand respectively.

Fusing: button stands, back neckline facing, lining of hidden closure – 1 detail.



#### **INSTRUCTIONS:**

- 1. Apply fusing to button stands, back neckline facing, lining of hidden closure.
- 2. Sew shoulder and bust darts on back and on front. Press depths towards center on back part and upwards on front.
- 3. Mark with three lines the closure opening on right side of right button stand: first line is parallel to button stand line and goes by 1.5 cm off the edge of button stand when ready; limit length of closure with second and third lines. Put fused facing onto right side of button stand right side downwards directed from edge of front band, aligning facing edge and marked line. Put the stitch at 0.5 cm from marked line along closure slit up to lines that limit the closure length. Put second facing of the closure edge-to-edge to first facing connecting stitch and put the stitch at 0.5 cm. On wrong side check you connected facing correctly (stitches must be parallel). Cut the slit through. Make cross slashes at 1-1.5 cm from the end of closure slit. Turn facing wrong side out, shaping from fused facing a frame that is equal the distance between stitches. Put fastening stitch into facing connecting seam. Press second facing towards inner edge of button stand and put fastening stitch at 0.1 cm off the facing connecting seam. Mark and serge buttonhole. Holes are punched on button stand together with fused facing. Straighten and fasten ends of closure from the wrong side with double back stitch on base of corners. Sew edges of the facings. Stay-stitch between each pair of buttonholes, length of stay-stitch is the same as frame's width. Press button stand.

  4. Put button stand onto right side of front right side downwards, pin together and overstitch along
- 4. Put button stand onto right side of front right side downwards, pin together and overstitch along button stand. Overstitch from front's side upwards up to marked line of neckline. Stitch lower edges of button stands to front exactly on hem marked line, leaving 1.5 cm to inner edge of button stand. Trim seams of lower corners of front band. Topstitch front band seam allowance onto button stand. Stitch at 0.2 cm off the seam. Turn front bands right side out, straighten seams.
- 5. Sew and press apart shoulder and side seams.
- 6. Sew and press apart shoulder edges of back neckline facing and of button stands. Overstitch the neckline of back and front parts, slash seam allowances, turn the facing and button stands right side out, press.
- 7. Sew and press apart elbow sleeve seam. Sew and press apart front sleeve seam. Press hem of sleeve.
- 8. Sew sleeves into armholes according to notches. Set in and sew shoulder pads and sleeve heads.
- 9. On lining details sew side seams and sew sleeves in. Serge allowances of side seams from hem up to waist. Turn seam allowance of lower edge of lining twice at 1.5 cm and topstitch.
- 10. Serge, press and undersew with invisible stitches seam allowance on hem of the garment. Stitch lining to inner button stand edges and back neckline facing. Start and end stitch in center of hem fold of main garment. Slash seam allowance on inner edge of button stand near start point of lining connection. Turn inside seam allowance of button stand from hem line up to slash and undersew with invisible stitches. Serge seam of lining and press towards lining.
- 11. Stitch lining to hem of sleeve. Press seam onto lining.
- 12. Put decorative stitches on right front, fastening the hidden closure.
- 13. On right front serge top buttonhole, sew buttons on left front.



# **TECHNICAL DRAWING:**

