

Sewing Pattern — Dress 4077

Recommendations on fabric: thin costume fabric of natural or mixed fibers.

You will also need: thin fabric fusing, blind zipper

If the pattern has double contour the seam allowances are included.

Seam allowances are NOT included by default and need to be added when laying out and cutting details if your pattern has single contour.

Seam allowance: all seams - 1 cm; on hem of the dress – 2.0 cm, along vent – 6 cm

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



CUTTING:

Fabric:

1. Upper back part - 2 details
2. Lower back part - 2 details
3. Upper left front part – 1 detail
4. Upper right front part – 1 detail
5. Lower front part - 1 detail
6. Sidebody – 2 details
7. Right part of collar – 2 details
8. Left part of collar – 1 detail
9. Flounce – 2 details
10. Sleeve - 2 details
11. Cuff - 2 details
12. Пoза – 1 detail

Fusing:

1. Right part of collar — 1 detail
2. Left part of collar — 1 detail
3. Cuff - 2 details

INSTRUCTIONS:

1. Apply fusing to details of collars.
2. Sew darts on details of back part. Press darts to middle seam. Sew top and lower parts of back part. Press seam downwards and serge.
3. Cut 5 cm along vertical edge of the vent on lower left back part. Apply fusing to both details of lower back part from wrong side. Mark middle seam line (vent foldline) on right side. Press left part on vent foldline, on right part press only seam allowance of right side of vent (6 cm) onto wrong side. Coincide details on middle seam and fix on top edge of vent. Serge middle edge of back part separately on every detail. Serge seam allowances of the vent. Sew middle edge of back part from zipper marker up to vent corner. Slash the corner of vent seam allowance on right part. Press seam allowances of middle seam apart, press vent seam allowances and fix them on right side with a machine stitch.
4. Sew darts on details of top front part. Press darts towards center.
5. Sew shoulder seams, press seam onto back part and serge.
6. Fold left part of collar right sides together and overstitch middle edge from fold up to marker. Slash seam allowances near marker. Turn collar out and press. Sew outer side of left part of collar into the neckline.
7. Fold details of right part of collar right sides together and overstitch outer side and middle edge up to marker. Slash seam allowances near marker. Turn collar out and press. Sew collar into the neckline: sew only outer part of collar from middle edge of back part up to marker «o», next slash seam allowance of inner part and sew in two edges together.
8. Sew zipper into the middle edge of back part.
9. Press open inner edge of left part of collar onto wrong side and topstitch in connection seam. Turn seam allowance near middle edge inwards and tack to zipper tape. Fold left part of collar in half and fix along front edge.
10. Sew front edge of top front part. Press seam allowances on right part and serge. Press open inner edge of right part of collar onto wrong side and topstitch in connection seam. Turn seam allowance near middle edge inwards and tack to zipper tape. Turn right part of collar on right part of front part, coincide lower point with marker «o», making a small fold, and fix along the lower edge.
11. Fold details of the flounce right sides together and overstitch on outer and lower edges (between markers «->»). Slash seam allowances in corner away, turn flounce onto right side, press. Make a plait on flounce, fix on top edge.
12. Stitch sidebodies to lower part of front part, inserting a flounce between left sidebody and front part. Press seam allowances onto sidebodies, serge.
13. Sew top and bottom front part. Press seam allowances downwards and serge.
14. Sew side seams, press seam onto back part and serge.
15. Sew edge of sleeve. Press seam allowances and serge. Sew sleeve in armhole, coinciding notches and gathering slightly on roundings. Press seam allowances and serge.
16. Fold cuff in half lengthwise right sides together and overstitch ends from the fold up to marker. Slash seam allowances in corner away, slash near marker. Fold cuff into ring and sew sections from marker up to edge. Turn cuff onto right side, straighten, press. Insert cuff into sleeve, coincide seam on cuff with marker and stitch to lower edge. Serge. Turn cuff onto right side.
17. Serge seam allowance of the dress hem, press onto wrong side and undersew with invisible stitches. Fasten seam allowance of vent to hem.
18. Fold detail of the rose in half lengthwise wrong sides together, serge edges. Stitch loosely along edges and gather ruffles. Shape a flower from details and fasten it on waist. Wear the with a belt.

TECHNICAL DRAWING:

