

## Shirt - Sewing Pattern #4711

Recommendations on fabric: natural/mixed fabrics suitable for blouses.

You will also need: fusible interfacing.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment and hem of sleeve – 1.2 cm.

### Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

### Note on length of fabric:

*Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.*



## CUTTING:

### Note on cutting:

*On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.*

*When sewing the garment, pay attention to notches, they must match up.*

Main fabric:

1. Back facing – cut 2
2. Back – cut 1 on fold
3. Front – cut 1
4. Collar – cut 4
5. Lapel – cut 4
6. Sleeve - cut 2

Fusible interfacing:

1. Back facing – cut 1
2. Collar – cut 2
3. Lapel – cut 2

## INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew outer back facing to back, seam allowances press towards facing.
3. Pin collar, right sides together, and sew ends and outer edge. Clip into seam allowances near notches, turn collar right side out, press. Pin lapels together right sides together, put in between the collar and sew collar and lapel according to markings, sewing the outer edge of lapel at the same time. Turn lapel right side out, straighten, press.
4. Pin right lapel at left and baste together along lower edge. Sew collar with lapel into front neckline, serge and press.
5. Serge inner edge of inner back facing. Pin facing onto back and serge the neckline (start and stop stitching exactly at the marked line of shoulder seam). Clip into curves. Put shoulder edge of front between inner facing and self back and sew. Serge, press towards back, turn garment right side out. Stitch-in-the ditch the back facing.
6. Sew in sleeve, press seam allowances towards sleeve and serge.
7. Sew side seam, and continue sewing the sleeve seam, serge and press.
8. Serge hem of garment and hem of sleeves, press onto wrong side and topstitch.

## TECHNICAL DRAWING:

