

Outdoor Jacket - Sewing Pattern #4828

Recommendations on fabric: natural/mixed double sided suiting fabrics, or fabrics suitable for coats.

You will also need: finishing bias tape (approximate length is given on the front pattern piece)

Seam allowances: Seam allowance along hem of garment, hem of sleeve, center front, neckline and upper pocket edge — 0 cm, all other seams 1 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Back – cut 1 on fold
2. Front – cut 2
3. Sleeve – cut 2
4. Pocket – cut 2

INSTRUCTIONS:

1. Serge lower and side edges of pocket. Sew bias tape to upper edge of pocket (pin bias tape to edge from the right side and sew, fold bias tape onto wrong side and topstitch onto garment along fold line). Turn seam allowances inside and press. Pin pocket onto right side of center piece and topstitch at 0.2 cm from edge.
2. Sew side and shoulder seams. Serge and press towards back.
3. Sew sleeve seam. Serge. Sew sleeve into armhole. Serge.
4. Sew bias tape to center front edge, neckline and hem of jacket. Sew bias tape to lower edge of sleeve (pin bias tape to sleeve edge from the right side and sew, fold bias tape onto wrong side and topstitch onto garment along fold line). Fold lower edge of sleeve upwards, making a cuff.

TECHNICAL DRAWING:

