

Jacket With Wrap - Sewing Pattern #2036

Recommendations on fabric: thin natural/mixed fabric suitable for coats.

You will also need: lining; fusible interfacing; 1 button.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment – 4 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Back – cut 1 on fold
2. Front right – cut 1
3. Front left – cut 1
4. Center front facing right – cut 1
5. Center front facing left – cut 1
6. Collar left – cut 2
7. Back neck facing – cut 1

8. Cuff – cut 2
9. Off-set welt – cut 2
10. Underlay piece – cut 2
11. Belt – cut 1

Lining:

1. Back – cut 1 on fold
2. Front – cut 2
3. Large pocket bag – cut 2
4. Small pocket bag – cut 2

Attention! Lining for back and front is cut using pattern blocks for shell, except for the width of back neckline facing and center front facing.

Fusible interfacing:

1. Front right – cut 1
2. Front left – cut 1
3. Center front facing right – cut 1
4. Center front facing left – cut 1
5. Collar left – cut 1
6. Back neck facing – cut 1
7. Off-set welt – cut 2

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Fold off-set welt in half lengthwise right sides together and sew short sides. Trim away corners, turn off-set welt right side out, straighten and press. Sew a decorative stitch at 0.7 from edge.
3. Mark the position of pocket. Draw a line on the off-set welt, which shows its width when ready. Topstitch small pocket bag onto inner side of welt. Sew welt to front along lower marked line of pocket. Topstitch underlay piece onto bigger pocket bag. Sew bigger pocket to the upper line of the pocket marking. Slash a pocket opening between the marked lines, making slashed cuts towards the corners of the marked pocket. Turn pocket lining onto wrong side. Straighten seam allowances and press. Sew together edges of pocket bags, fixing corners of pocket. Topstitch shorter ends of off-set welt onto front.
4. Sew upper edges of sleeves, press seam apart. Sew lower edges of sleeves, sewing the side edges at the same time, press seam apart.
5. Sew center collar seam, press seam apart. Sew collar into neckline, clipping into seam allowance near corner, clip seam allowances and press apart.

6. Sew shoulder seams of back neckline facing and center front facings, press seam apart. Sew center collar seam, press seam apart. Sew collar into neckline facings, clipping into seam allowance near corner, clip seam allowances and press apart.
7. Pin center front facing onto front right sides together and sew lower corner, center front edge and collar. Clip into curves, trim away corners. Turn right side out center front facings onto wrong side and press.
8. Sew cuff into a ring, press seam apart. Fold cuff in half lengthwise and press right side out. Sew outer side of cuff to lower edge of sleeve, press towards cuff.
9. Sew seams on lining, leaving an opening for turning in the left side seam. Press. Sew lining to buttonstands and facing, press seam. Turn garment right side out, straighten seams. Slip stitch together seam allowances along collar seams. Sew lining to hem of garment through the opening and sew lining to inner side of cuff. Sew the opening closed.
10. Sew a decorative stitch along center front edge and collar at 0.5 cm from edge.
11. Make button loop on front. Sew on button.
12. Fold belt in half lengthwise right sides together and sew around all edges, leaving an opening for turning. Seam Allowances trim away corners, turn belt right side out, straighten, press. Sew a decorative stitch along edge at 0.5 cm.

TECHNICAL DRAWING:

