

Sewing Pattern — Dress 4036

Recommendations on fabric: thick silk fabric of contrast colors suitable for dresses

You will also need: fusing; decoration tape of 1 cm wide and approximately 30 cm long; blind zipper

If the pattern has double contour the seam allowances are included.

Seam allowances are NOT included by default and need to be added when laying out and cutting details if your pattern has single contour.

Seam allowance: all seams - 1 cm; lower edge of sleeve – 1.5 cm; hem of the dress – 3.0 cm.

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



CUTTING:

Fabric:

1. Central lower part of the back - 2 details
2. Side lower part of the back - 2 details
3. Central lower part of the front - 1 detail
4. Side lower part of the front - 2 details

Decoration fabric:

1. Central upper part of the back - 2 details
2. Side upper part of the back - 2 details
3. Central upper part of the front – 2 detail
4. Side upper part of the front – 2 details
5. Sleeve - 2 details
6. Back neckline facing – 2 details
7. Front neckline facing – 2 details

Fusing:

1. Back neckline facing – 2 details
2. Front neckline facing – 2 details

INSTRUCTIONS:

1. Apply fusing to neckline facings.
2. Sew princess edges on upper part of the back, press seam allowances towards center and serge. Sew princess edges on lower part of the back, press seam allowances towards center and serge. Sew upper and lower parts of the back, press seam allowances upwards and serge.
3. Apply fusing to wrong side of the vent on both details of central lower part of the back. Mark center seam line (vent fold line) on the right side. Serge center edge of the back separately on each detail, serging the vent at the same time. Sew center edge of the back from the notch up to the vent edge. Slash vent's seam allowance corner on the right part. Press allowances of center seam apart, pressing the slit for zipper and vent. Press right side of the vent at 1 cm onto wrong side and topstitch. Press vent seam allowances to left side and topstitch on the top with machine stitch. Sew in zipper.
4. Sew princess edges on upper part of the front, press seam allowances towards center and serge.
5. Serge outer edge of the back / front part neckline facings. Fold front neckline facings with the front and overstretch low neck edge from the notch up to shoulder edge, leaving 3-4 cm to it. Slash seam allowance near the notch; turn the facing onto right side.
6. Sew princess edges on lower part of the front, press seam allowances towards center and serge. Stitch upper part of the front to lower one, press seam allowances upwards and serge. Topstitch free edge of front neckline facing into upper and lower parts connecting seam.
7. Sew side and shoulder edges, press seam onto back part and serge.
8. Sew shoulder seams of the facings, fold them with the dress and overstretch back neckline edge and section of low neck edge. Slash seam allowances on rounded parts, turn facings onto right side. Turn seam allowance of facing's center edge inside and tack to zipper tape. Put decorative stitch along back neckline and low neck.
9. Serge lower edge of sleeve, press onto wrong side and topstitch. Sew edge of sleeve. Press and serge seam allowances. Sew sleeve into armhole, leveling notches. Press and serge seam allowances.
10. Press hem seam allowance of the dress onto wrong side, turn inside again at 1 cm and topstitch.
11. Shape a bow from decoration tape and fix it according to technical drawing.

TECHNICAL DRAWING:

