

Jacket With Buckle - Sewing Pattern #2068

Recommendations on fabric: natural/mixed suiting fabrics.

You will also need: fusible interfacing; lining; shoulder pads; 1 buckle.

Seam allowances: all seams 1 cm. Seam allowance for hem of sleeve – 3.0 cm.

Attention! Pattern blocks are drafted as seen from the right side, when cutting, please place them with the text and markings down onto the fabric.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Upper center back – cut 2
2. Lower center back – cut 1
3. Upper side back – cut 2
4. Lower side back – cut 2

5. Upper center front – cut 2
6. Upper side front – cut 2
7. Lower side front right – cut 1
8. Lower center front right – cut 1
9. Lower front left – cut 1
10. Lower collar - cut 1
11. Upper collar – cut 1
12. Center front facing – cut 2
13. Back neck facing – cut 1
14. Upper sleeve – cut 2
15. Lower sleeve – cut 2
16. Strap – cut 2

Lining:

1. Upper center back – cut 2
2. Lower center back – cut 1
3. Upper side back – cut 2
4. Lower side back – cut 2
5. Upper center front – cut 2
6. Upper side front – cut 2
7. Lower side front right – cut 1
8. Lower center front right – cut 1
9. Lower front left – cut 1
10. Upper sleeve – cut 2
11. Lower sleeve – cut 2

Attention! Front and back from lining are cut using the pattern blocks for self fabric, with the exception for the areas of center front facing and back neckline facing.

Fusible interfacing:

1. Upper center front – cut 2
2. Center front facing – cut 2
3. Back neck facing – cut 1
4. Upper collar - cut 1

INSTRUCTIONS:

1. Apply fusible interfacing. Apply fusing on front along the lapel fold , its width should equal 1 cm (fusible interfacing).
2. Fold strap in half lengthwise right sides together and sew along long side and one short side. Trim away corners, turn the piece right side out, press.

3. Sew center seam on upper back, press seam apart. Sew upper center back to upper side back, press seam apart. Sew upper center front to upper side front, press seam apart.
4. Sew and press apart the shoulder and side seams of upper part, inserting strap into left side seam.
5. Sew center lower back to side lower back, press seam apart. Sew right lower center front to right lower side front, press seam apart. Sew side edges of lower parts and press apart.
6. Repeat for lining of lower part. Pin Shell to lining and sew lower edge. Clip into curves, turn right side out, press. Make and baste a box pleat on lower left front.
Sew lower part of Shell to upper part of Shell (seam allowances along center front protrude by 1 cm).
7. Pin upper collar to lower collar and sew corners and fall. Start and stop sewing exactly at the marked line of the seam between collar and garment. Trim away corners, clip into seam allowance near notch. Turn the collar right side out, straighten and press.
8. Sew and press apart shoulder seams of back neckline facing and buttonstand.
9. Place center front facing onto front right sides together, pin together and sew along the center front edge, inserting strap. Sew upwards up to the notch marking the end of collar seam. Trim away corners. Topstitch seam allowance along center front edge onto center front facing along the closure, and onto front along the part, which is folded away. Place stitch line at 0,2 cm from seam. Turn buttonstands (center front edges) right side out, straighten seams.
10. Sew lower collar into neckline of Shell, sew upper collar into back neckline facing and center front facing. Press seam allowances of the collar seam apart and slipstitch them together close to the seam.
11. Sew elbow seam on sleeve, press seam apart. Press hem of sleeve. Sew and press apart front sleeve seam. Sew sleeves into armholes matching notches, adjusting ease along upper side of sleeve cap. Sew shoulder pads.
12. Sew seams and sew in sleeves on upper pattern pieces from lining, leaving an opening for turning in front right sleeve seam.
13. Sew lining to inner edges of buttonstands and to back neckline facing. Turn center front facing and lining onto wrong side, and sew them to jacket, placing the lower part between Shell and lining. Turn jacket right side out through the opening in seam. Sew lining to hem of sleeve. Sew the opening in the sleeve closed.
14. Thread strap into buckle and slipstitch.

TECHNICAL DRAWING:

