

Blouse With Wrap - Sewing Pattern #2094

Recommendations on fabric: natural/mixed fabric suitable for dresses.

You will also need: lining; fusible interfacing, 3 outer buttons; 1 inner button.

Seam allowances: all seams 1 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Back - cut 2
2. Right front — cut 1
3. Left front — cut 1
4. Lapel — cut 4
5. Collar — cut 2
6. Center front facing — cut 2
7. Back neck facing - cut 1

Lining:

1. Back lining – cut 2
2. Front lining — cut 2

Fusible interfacing:

1. Lapel — cut 2
2. Collar — cut 1
3. Center front facing — cut 2
4. Back neck facing – cut 1

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew darts on back, press bulk towards center. Sew center back seam, press seam apart.
3. Make and baste pleats on right front (fold bulk towards bottom). Make pleat on left front 8-10 cm deep and sew it (fold bulk towards bottom) .
4. Sew side and shoulder seams, press seam apart.
5. Pin upper collar with lower collar and sew collar fall and collar corner. Trim corners, turn right side out, straighten and press collar. Pin lapels together by two and sew corner and outer edge of lapel. Clip near the notch on the lapel, turn lapel right side out, straighten and press. Sew the lapel edge: sew upper collar to upper lapel, sew lower collar to lower lapel. Press seams apart. Slipstitch seam allowances together close to stitch line. Sew collar and lapel into the neckline.
6. Cut (or take ready) bias tape, its width should equal 2.5 cm and its length should equal 15 cm for loop buttonholes. Fold tape in half lengthwise right sides together and stitch at 0.3 cm from fold. Cut away seam allowances close to seam, turn tape right side out and straighten rolled hem. Cut into three parts. Adjust the length of buttonholes. Topstitch button loops onto right front (folds are directed away from the edge).
7. Sew side seams of back neckline facing and buttonstands, press seam apart. Sew darts and seams on lining, leaving an opening for turning in left side seam. Sew lining to inner edges of center front facings (button stands) and to facing.
8. Pin center front facing and facing onto Shell, right sides together, pin together and sew buttonstand, front neckline, back neckline and lower edge. Clip into seam allowances on curves, trim away corners. Turn garment right side out, straighten, press.
9. Sew armhole in two steps through the opening in side seam: sew back armhole from shoulder seam to side seam, and front armhole from shoulder seam to side seam. Sew the opening closed.

10. On left front make button loop, sew on inner button. Sew outer buttons.

TECHNICAL DRAWING:

