

Blouse With Short Sleeve - Sewing Pattern #2109

Recommendations on fabric: natural/mixed fabrics suitable for blouses.

You will also need: fusible interfacing; 6 buttons.

Seam allowances: Seam allowance for hem of garment and hem of sleeve – 2 cm; other seams – 1 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

- 1. Back yoke cut 1
- 2. Back cut 1 on fold
- 3. Front cut 2
- 4. Front yoke cut 2
- 5. Sleeve cut 2
- 6. Placket cut 4



Fusible interfacing:

1. Placket — cut 2

INSTRUCTIONS:

- 1. Apply fusible interfacing to plackets.
- 2. Sew a gathering stitch along upper edge of front and gather fullness. Sew front yoke to front. Press towards top and serge.
- 3. Sew back yoke to yoke. Serge and press towards top.
- 4. Sew side and shoulder seams. Serge seams and press towards back.
- 5. Sew center edges of plackets. Press seam apart. Pin together plackets right sides together and sew center front facings and neckline. Clip seam allowances, turn right side out and press.
- 6. Sew plackets to front and to back. Clip into seam allowances of neckline, serge and press towards Shell
- 7. Sew sleeve seam, serge and press towards back. Sew sleeves into armholes, serge and press.
- 8. Serge hem of garment and hem of sleeve, turn inside and topstitch.
- 9. Make buttonholes and sew on buttons on plackets.

TECHNICAL DRAWING:



