

Hoodie - Sewing Pattern #2358

Recommendations on fabric: natural/mixed knit fabric of small stretchiness.

You will also need: rib knit fabric or knit fabric of high stretchiness; decorative cord; cord ends for the cord.

Seam allowances: all seams - 1 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.



Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.

CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Back - cut 1 on fold
2. Front - cut 1 on fold
3. Sleeve — cut 2
4. Pocket - cut 1
5. Hood - cut 1 on fold
6. Center hood - cut 1
7. Hood facing - cut 1

Main fabric 1:

1. Hem facing – cut 1
2. Cuff – cut 2

INSTRUCTIONS:

1. Serge the edge of one-piece facing of the pocket opening. Fold under the pocket facing and press and topstitch. Serge pocket edges. Fold under the side and lower edges and press. Pin pocket to front, right sides together, along the upper marking line the pocket placement (the lower edge of pocket is directed towards the neckline) and sew. Fold away pocket down. Topstitch pocket onto front along the side edges.
2. Sew sleeve to back, press seam allowances towards sleeve and serge. Sew sleeve to front, press seam allowances towards sleeve and serge.
3. Sew sleeve seam and side seam continuously, press seams towards back and serge.
4. Sew center part to hoods, press seam allowances onto central part and serge. Make button holes for cord. Sew hood into neckline, serge and press.
5. Serge inner edge of hood facing. Pin facing onto hood right sides together and sew outer edge. Clip into curves, turn facing under, press. Topstitch facing onto hood, making a casing.
6. Sew cuff into a ring, press seam apart. Fold cuff in half lengthwise right side out and press. Sew cuff to lower edge of sleeve, slightly stretching it. Serge and press.
7. Sew hem facing into a ring, press seam apart. Fold facing in half lengthwise wrong sides together and press. Sew facing to hem of garment, placing the seam under the left side seam and slightly stretching it. Serge and press.
8. Thread cord into hood, attach cord ends.

TECHNICAL DRAWING:

