

Sewing Pattern — Dress 5998

Recommendations on fabric: natural or mixed dress fabrics.

You will also need: lining; fusing; blind zipper, 6 buttons

If the pattern has double contour the seam allowances are included.

Seam allowances are NOT included by default and need to be added when laying out and cutting details if your pattern has single contour.

Seam allowance: hem of dress, hem of sleeve - 2 cm, top edge of front part inset – 3 cm, vent edge - 6 cm, all other seams - 1 cm

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



CUTTING:

Main fabric:

1. Upper back part – 2 details
2. Lower back part – 2 details
3. Front part inset – 1 detail
4. Central front part - 2 details
5. Side upper part of the front– 2 details
6. Lower front part – 1 detail
7. Sleeve – 2 details
8. Panel of sleeve – 2 details
9. Back neckline facing – 2 details

Lining:

1. Central front part - 2 details
2. Side upper part of the front – 2 details

Fusing:

1. Back neckline facing – 2 details
2. Vent – 2 details
3. Panel of sleeve – 2 details

INSTRUCTIONS:

1. Sew darts on details of upper back part, lower back part and lower front part. Press depths towards center of back part and of front part correspondingly.
2. Serge upper edge of front part inset. Turn seam allowance inside and topstitch. Fold details of front part decoration right sides together and overstretch along two outer sides. Turn onto right side, slashing corner away and press. Sew upper central front part with lining along outer edge, inserting front part inset between them. Turn onto right side and press. Sew side upper front part and lining along outer edge, inserting central part (with lining) between them. Then sew front part with lining as one detail.
3. Sew upper and lower front part. Serge and press downwards. Sew upper and lower back part. Press seam allowances downwards and serge.
4. Cut off 5 cm on left lower part of the back along vent's vertical edge. Apply fusing to wrong side of the vent on both details of lower part of the back part. Mark center seam line on right side (vent foldline). Press left part along vent foldline, on right part press only seam allowance of right side of the vent (6 cm) onto wrong side. Align details along center seam and fix on top edge of the vent. Serge center edge of back part separately on each detail. Serge seam allowances of the vent. Sew center edge of back part from zipper marker up to vent corner. Slash vent allowance corner on right part. Press apart seam allowances of center seam, press seam allowances of the vent and fix them with machine stitch. Sew in zipper from top edge up to the notch.
5. Overstretch the back part neckline with facing, starting and finishing the stitch exactly near shoulder seam. Slash seam allowances.
6. Sew shoulder seams, inserting front part between back part and back part facing. Press seam allowances towards back part, serge. Turn the facing onto wrong side. Sew side seams. Serge and press towards back part.
7. Turn lower edge of sleeve twice inside at 1 cm and topstitch. Sewing the vent: Cut the sleeve along marked line, slashing the corner in top part of the slit. Turn section from the slit up to marked line that is 1.7 cm, twice inside at 0.5 cm and topstitch. Fold panel in half lengthwise right sides together and overstretch corner up to cross marker and overstretch lower edge. Cut seam allowances off close to the stitch, slash seam allowance near the end of the stitch. Turn the panel out, press and stitch along foldline up to cross marker at 0,1 cm. Fold panel with the sleeve right sides together and stitch with inner side along marked line. Slash sleeve near the end of the stitch crosswise from the slit up to connecting line. Turn panel onto right side, turn open edge and stitch. Align panel with marked line on the sleeve and topstitch top corner on contour and along cross marker.
8. Sew and serge edges of sleeves. Sew in the sleeve, easing in on rounded parts. Serge and press.
9. Serge hem of garment. Turn onto wrong side, press and topstitch.

TECHNICAL DRAWING:

