

Wrap Dress - Sewing Pattern #2729

Recommendations on fabric: natural/mixed fabric suitable for dresses.

You will also need: fusible interfacing; 1 button.

Seam allowances: all seams 1 cm; seam allowance for hem of garment - 2.0 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Upper back - cut 2
2. Lower back - cut 2
3. Upper front — cut 2
4. Lower front — cut 2
5. Sleeve - cut 2
6. Center front facing - cut 2
7. Back neck facing - cut 1

8. Cuff - cut 2
9. Belt - cut 2

Fusible interfacing:

1. Back neck facing - cut 1
2. Center front facing - cut 2
3. Cuff - cut 2

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew darts on upper backs and lower backs. Press bulk towards center. Sew the center edges on the upper back and the lower back. Serge the seam allowances and press towards left. Sew upper part to lower part. Serge seams and press towards top.
3. Sew darts on upper and lower fronts. Cut away the bulk of the bust darts with a serger and press towards the center. Sew upper front to lower front. Serge seams and press towards top.
4. Sew shoulder seams, clipping into the seam allowance of the shoulder seam on Front, press towards the back and serge. Sew collar seam, press the seam apart. Sew in the collar into the back neckline, press seam allowances towards the collar.
5. Fold the left belt in half lengthwise and sew longer and one shorter edge. Trim seam allowances, turn right side out and press. Finish the right belt in the same way.
6. Sew the side seams, inserting the left belt into the left side seam. Serge seams and press towards back.
8. Sew the shoulder seams on Back Neckline Facing and Center Front Facings, clip into corners and press apart. Sew collar seam, press the seam apart. Sew the collar into the facing's neckline, press the seam apart. Serge the outer edge of center front facings and of neckline facing.
9. Pin facings and center front facings to front right sides together. Sew the collar edge and the center front edges, inserting the right belt into the right center edge. Clip into curves, turn collar onto right side and center front facing onto right side, straighten seams, press. Slip stitch together seam allowances along collar seams.
10. Sew sleeve seam, press towards back and serge.
11. Sew cuff into a ring, press the seam apart. Fold cuff in half lengthwise and press. Sew the cuff to the sleeve from the wrong side. Serge, fold the cuff towards top, onto right side and press. Sew the cuff to the sleeve by hand.
12. Sew sleeves into armholes, serge and press.

13. Serge the lower edge of garment, press onto wrong side and topstitch.
14. Make a button hole on the left center front facing. Sew on inner button.

TECHNICAL DRAWING:

