

## 2736 - Sewing Pattern #2736

Recommendations on fabric: natural/mixed fabrics suitable for blouses.

You will also need: fusible interfacing; 5 buttons.

Seam allowances: Seam allowance for hem of garment and hem of sleeve - 2 cm; other seams - 1 cm.

### Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

### Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



## CUTTING:

### Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Back - cut 1 on fold
2. Front - cut 2
3. Sleeve - cut 2
4. Collar — cut 2
5. Casing - cut 1 on fold

Fusible interfacing:

1. Collar — cut 1

## INSTRUCTIONS:

1. Apply fusible interfacing. Also apply fusible interfacing to the one-piece placket on front.
2. Sew front darts, press bulk towards top.
3. Fold the one-piece placket onto wrong side and press according to marked line center front facings. Fold inside the longer seam allowance of the one-piece placket and topstitch placket onto front.
4. Sew shoulder and side seams, press towards the back and serge.
5. Pin upper collar to lower collar, right sides together, sew ends of collar and collar fall. Start and stop sewing exactly at the marked line of seam. Trim seam allowances, turn the collar right side out, straighten and press. Lower collar sew into neckline, fold under the raw edge of upper collar and stitch in the ditch.
6. Serge seam allowances of the shorter edges of casing, press onto wrong side and topstitch. Fold seam allowances of the longer edges of casing onto wrong side and press. Pin the casing onto the right side of the garment according to markings and topstitch.
7. Sew sleeve seam, press towards the back and serge. Sew sleeves into armholes, serge and press.
8. Fold inside the hem of garment and the hem of sleeve at 1 cm, then again at 1 cm and topstitch.
9. Make buttonholes on right front, sew on buttons on the left one.
10. Cut a bias tape for the tie from the main fabric , its width should equal 4 cm and its length should equal the waist girth + 50 cm. Fold tape in half lengthwise and press. Press outer seam allowances towards center, topstitch along the edge. Thread the tie into the casing.

## TECHNICAL DRAWING:

