

Coat In Sport Style - Sewing Pattern #2733

Recommendations on fabric: soft natural/mixed fabric suitable for coats (bouclé).

You will also need: fusible interfacing; 1 separating zipper; two of the zipper at pockets; 2 buttons.

Seam allowances: all seams - 1 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Back - cut 1 on fold
2. Back yoke - cut 1
3. Front yoke - cut 2
4. Front - cut 2
5. Sleeve - cut 2
6. Collar - cut 2
7. Cuff - cut 2

8. Center front facing - cut 2
9. Back neck facing - cut 1
10. Flap - cut 2
11. Placket - cut 1 on fold

Fusible interfacing:

1. Center front facing - cut 2
2. Collar - cut 1
3. Cuff - cut 2
4. Back neck facing - cut 1
5. Flap - cut 2

Lining:

1. Large pocket bag - cut 2
2. Small pocket bag - cut 2
3. Flap - cut 2

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew back yoke to yoke. Serge and press towards top.
3. Mark the position of pockets with parallel lines. Cut the slit for pocket opening. Slash diagonally at 1-1.5 cm from the end of the marked slit. Turn the seam allowances onto the wrong side through the resulting opening, straighten edges. Pin zipper under the opening so that you can see the teeth and sew. Sew right side of lining to the wrong side of zipper tape. Sew edges of lining.
4. Pin the pocket flaps together pairwise, right sides together and sew the side and the lower edges. Trim seam allowances, turn right side out and press.
5. Sew front yoke to front, inserting flap. Serge seams and press towards top.
6. Sew side and shoulder seams, press towards the back and serge. Sew outer collar into neckline. Press the seam apart.
7. Sew shoulder seams of back neckline facing and center front facings. Press the seam apart. Serge outer edges. Sew inner collar into neckline. Press the seam apart.
8. Make and baste pleats along the lower edges of the front and the back. Sew the outer side of placket to the garment. Press down. Sew the center front facing to the inner edge of the placket.
9. Pin the center front facing, the facing, and the collar onto the right side of the garment, baste together along

the seams, and sew the center front edges and the collars, inserting zipper. Trim away corners. Fold center front facing and facing onto wrong side and press the center front edges. Fold inside the upper edge of the placket and stitch-in-the-ditch along seam of outer side. Baste collars together. Baste together along the shoulder edges center front facings and top of garment.

10. Serge the sleeve edges separately. Sew the sleeves from the top to the slit mark. Press the seam apart. Sew a fastening stitch along the slit.

11. Make and baste the pleat at the bottom of the sleeve. Fold cuffs in half lengthwise right sides together and sew side edges and corner. Start and stop stitching exactly at the marked line of the cuff seam. Clip into seam allowance near the notch. Turn the piece right side out, press. Sew the outer part of the cuff to the sleeve, fold inside the inner side of the cuff, and topstitch into the seam of the outer cuff cuffs.

12. Sew sleeves into armholes, serge and press.

13. Make buttonholes and sew on buttons at cuffs.

TECHNICAL DRAWING:

