

Blouse With Button Loop On The Front Neckline - Sewing Pattern #2744

Recommendations on fabric: natural/mixed fabrics suitable for blouses.

You will also need: fusible interfacing, 1 button.

Seam allowances: all seams 1 cm. Seam allowance along the lower edge of the garment - 3 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Back - cut 1 on fold
2. Front - cut 2
3. Sleeve - cut 2
4. Cuff - cut 2
5. Collar - cut 2
6. Center front facing — cut 2

7. Buttonloop - cut 1

Fusible interfacing:

1. Center front facing — cut 2
2. Buttonloop - cut 1
3. Cuff - cut 2
4. Collar - cut 1

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew front darts, press bulk towards top.
3. Fold the button loop in half lengthwise right sides together and sew along longer and one shorter sides. Turn the piece right side out, straighten, press.
3. Snip into seam allowances on the fronts near the mark for neckline slit, sew center seam on front, press the seam apart and serge. Snip into seam allowances on center front facings near the mark for neckline slit, sew the center seam of the center front facings, press the seam apart and serge. Serge the outer edge.
4. Pin the center front facings onto the front, right sides together and sew the neckline, inserting the button loop on the right side according to the markings. Press seam, turn the center front facings onto wrong side, straighten, press. Topstitch the center front facings onto front at 0.5 cm from the outer edges.
5. Sew side and shoulder seams, press towards the back and serge.
6. Pin together collars right sides together and sew ends and collar fall. Start and stop stitching exactly at the marked collar seam. Clip seam allowances, trim away corners, turn collar right side out, straighten and press. Sew the upper collar into the neckline, fold inside the seam allowance of the lower collar and topstitch into the seam.
7. Sew sleeve seam, press towards the back and serge. Sew sleeves into armholes, serge and press.
8. Sew cuff into a ring, press the seam apart. Fold cuff in half lengthwise and press right side out. Sew the cuff to the sleeve from the wrong side, serge. Fold cuff onto right side and press. Sew the cuff to the sleeve by hand.
9. Serge lower edge, press onto wrong side and topstitch.
10. Sew on a button on the left side of the slit on the front.

TECHNICAL DRAWING:

