

Jacket With Slanted Closure - Sewing Pattern #2748

Recommendations on fabric: thin natural/mixed fabric suitable for coats.

You will also need: fusible interfacing; lining; shoulder pads; 2 zippers; separating zipper; 2 decorative push buttons.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment and hem of sleeve - 3 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Center back - cut 2
2. Side back - cut 2
3. Lower back - cut 1 on fold
4. Center front right - cut 1
5. Center front left - cut 2
6. Side front - cut 2

7. Lower front left - cut 1
8. Lower front right - cut 1
9. Collar — cut 2
10. Center front facing right — cut 1
11. Back neck facing - cut 1
12. Upper sleeve - cut 2
13. Lower sleeve - cut 2

Lining:

1. Center back - cut 2
2. Side back - cut 2
3. Lower back - cut 1 on fold
4. Center front right - cut 1
5. Side front - cut 2
6. Lower front right - cut 1
7. Lower front left - cut 1
8. Upper sleeve - cut 2
9. Lower sleeve - cut 2

Lining is cut using the pattern pieces for the main fabric, except for the width of the back neckline facing and the right center front facing.

Fusible interfacing:

1. Center front left - cut 2
2. Center front right - cut 1
3. Lower front right - cut 1
4. Lower front left - cut 1
5. Collar — cut 1
6. Center front facing right — cut 1
7. Back neck facing - cut 1

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew side backs to center back, press towards center. Sew the center back seam, press the seam apart. Sew upper back to lower back, press the seam allowances towards bottom.
3. Sew princess seam of right front, press towards center. Sew upper right front to lower right front, press the seam allowances towards bottom. Sew upper left front to lower left front, press the seam allowances towards bottom.
4. Mark the position of pockets with parallel lines. Cut the slit for pocket opening. Slash diagonally at 1-1.5 cm

from the end of the marked slit. Turn the seam allowances onto the wrong side through the resulting opening, straighten edges. Pin zipper under the opening so that you can see the teeth and sew. Sew right side of lining to the wrong side of zipper tape. Sew edges of lining.

5. Sew the princess seam of left front, inserting the left part of the zipper in between the pieces. Press the seam allowances away from the center. Sew right side of zipper to the edge of right front, teeth are directed away from the edge.
6. Sew the shoulder seams and the side seams of the garment, press the seam apart.
7. Sew the upper collar into the neckline of the garment. Start and stop stitching exactly at the mark of the beginning of lapel. Clip into seam allowance near the notch, press apart.
8. Sew side seams of center front facings and back neckline facings, press the seam apart. Sew the lower collar into the neckline of the center front facing and of the facing. Start and stop stitching exactly at the mark of the beginning of lapel. Clip into seam allowance near the notch, press apart.
9. Pin center front facings onto garment right sides together and sew center front facings, lapels, collar and the lower corner of the front piece. Trim away corners, turn pieces right side out, press.
10. Sew elbow seam on sleeve, press the seam apart. Press the hem of sleeve. Sew and press apart front sleeve seam. Sew sleeves into armholes matching notches, adjusting ease along upper side of sleeve cap. Sew shoulder pads.
11. Sew together pieces of lining in the same way as you have sewn pieces from main fabric, leaving an opening in left elbow seam of sleeve. Sew lining to facing and to central front facings. Turn garment right side out, straighten seams.
12. Mark the hem, fold inside and press. Sew lining to the hem of the garment and to the hem of the sleeve. Sew the opening closed.
13. Install decorative push buttons on the lapel ends.

TECHNICAL DRAWING:

