

## Coat - Sewing Pattern #2759

Recommendations on fabric: Mixed/natural fabrics suitable for coats.

You will also need: fusible interfacing.

Seam allowances: all seams 1 cm. Seam allowance along hem of garment and hem of sleeve - 3 cm.

### Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

### Note on length of fabric:

*Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.*



## CUTTING:

### Note on cutting:

*On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.*

*When sewing the garment, pay attention to notches, they must match up.*

Main fabric:

1. Back - cut 1 on fold
2. Upper front - cut 2
3. Lower front - cut 2
4. Sleeve - cut 2
5. Center front facing - cut 2
6. Back neck facing - cut 1

Lining:

1. Back - cut 1 on fold
2. Front - cut 2
3. Sleeve - cut 2

Fusible interfacing:

1. Center front facing - cut 2
2. Back neck facing - cut 1

Back lining is cut using the pattern pieces for the main fabric except for the width of the back neckline facing.

## INSTRUCTIONS:

1. Apply fusible interfacing. Apply fusible interfacing to the seam allowance of pocket.
2. Sew the lining of pocket to the upper front and to the lower front. Serge and press towards bottom. Pin fronts right sides together and sew the pieces together from the center front edge to the marking for pocket opening and from the marking for pocket opening up to the side seam. Sew pocket bags together.
3. Sew shoulder seams. Press the seam apart.
4. Sew sleeves to armholes. Press the seam apart. Sew side seams and sleeve seams. Press seams towards back.
5. Sew side seams of back neckline facing and central front facings, press seam apart. Serge the outer edge. Pin center front facings onto the main piece right sides together and sew center front edge, neckline and lower edge. Trim away corners, fold center front facings and neckline facing onto wrong side, straighten, press.
6. Sew together pieces of lining in the same way as you have sewn pieces from main fabric, leaving an opening in the left seam of the sleeve. Sew lining to facing and to central front facings. Turn garment right side out, straighten seams. Sew the facing to the shoulder seams by hand.
7. Mark the hem, fold inside and press. Sew lining to the hem of the garment and to the hem of the sleeve. Sew the opening closed.

## TECHNICAL DRAWING:

