

## Sewing Pattern — Dress 5949

Recommendations on fabric: natural or mixed thin costume fabric, knit fabric for sleeves

You will also need: blind zipper, 1 button, lining.

If the pattern has double contour the seam allowances are included.

If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out and cutting details.

Seam allowances: all seams - 1 cm, on hem of the garment and hem of sleeve – 3 cm.

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



## **CUTTING**:

## Main fabric:

- 1. Central back part 2 details
- 2. Side back part 2 details
- 3. Central front part 1 detail
- 4. Side front part 2 details
- 5. Collar 1 detail

#### Knit fabric:

- 1. Back part of sleeve 2 details
- 2. Front part of sleeve 2 details

## Lining:

- 1. Central front part 1 detail
- 2. Side back part 2 details
- 3. Central front part 1 detail
- 4. Side front part 2 details

Lining details are 5 cm shorter than main fabric details.



### **INSTRUCTIONS:**

- 1. Sew princess seams on back part, press seam allowances towards center and finish them. Apply fusing to wrong side of the vent on both details of central back part. Mark center seam line (vent fold-line) on the right side. Finish center edge of back part separately on each detail, finishing the vent at the same time. Sew center edge of back part from top edge up to the vent's edge. Slash away corner of vent's seam allowance on right part. Press seam allowances of center seam apart. Press right side of the vent at 1 cm and topstitch. Press seam allowances of the vent to left side and topstitch on top with machine stitch.
- 2. Sew princess edges and center edge of back part from lining lining. Press seam allowances and finish them. Cut a slit for the vent, finish the edge. Press lower edge twice onto wrong side and topstitch. Put lining onto main fabric detail of back part wrong sides together, attach on edges and then process as one detail.
- 3. Sew princess edges of front part, press seam allowances towards center and finish them. Sew princess edges of front part from lining, press seam allowances towards center and finish them. Put lining onto main detail right sides together, mark slit line and put along it (from the left and from the right) the stitch at 0.1 cm, bringing to null near lower point. Cut the slit between stitches, turn lining out, straighten. Press lower edge twice onto wrong side and topstitch. Attach on edges to main detail and then process as one detail.
- 4. Stitch back parts of sleeves to back part. Stitch front parts of sleeves to front part. Press seam allowances onto the sleeve and finish them.
- 5. Sew top edges of sleeves. Press seam allowances towards back part and finish them.
- 6. Finish hems of left sleeve and left side edges. Sew the sleeve from hem up to top zipper marker and from lower marker up to hem of the dress, press seam allowances apart, pressing the slit for zipper. Sew zipper in. Sew with one seam hem of right sleeve and right side seam, press seam onto back part and finish it.
- 7. Cut a bias tape of 2.5 cm wide and 5 cm long. Fold bias tape in half lengthwise right sides together and stitch at 0.3 cm off the fold. Cut off seam allowances close to the stitch, turn bias tape out and straighten. Make a loop buttonhole for the button. Fold collar in half lengthwise right sides together and overstitch ends and inner edge up to the long marker, inserting the loop buttonhole. Start and end the stitch exactly near marked line of collar connecting seam. Slash seam allowances near the marker. Turn ready collar out, straighten corners and press. Sew outer edge of collar into the neckline, press seam onto collar. Turn open inner edge of collar inside and topstitch into collar connecting seam. Put the dress on, shape the frill, fasten pleats together. Sew the button under the collar in accordace with the loop buttonhole.
- 8. Finish hem of the garment and hem of sleeves, press to wrong side and undersew with invisible stitches.



# **TECHNICAL DRAWING:**

