

## Sewing Pattern — Coat 5917

Recommendations on fabric: whipcord

You will also need: fusing; 2 eyelets; cord for the belt; zipper (length of the zipper is shown on front part pattern)

If the pattern has double contour the seam allowances are included.

If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out and cutting details.

Seam allowances: hem of the garment / sleeve – 3 cm, top pocket edges – 2 cm, short edges of pocket plackets - 3 cm (cut off surpluses after stitching plackets to pocket), lower edge of front band - 0 cm, all other seams -1 cm

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



### **CUTTING:**

#### Main fabric:

1. Back part – 2 details
2. Front part - 2 details
3. Sleeve - 2 details
4. Collar – 2 details
5. Placket – 1 detail
6. Front band – 2 details
7. Upper flap – 4 details
8. Upper pocket – 2 details
9. Placket of upper pocket – 2 details
10. Lower flap – 4 details
11. Lower pocket – 2 details
12. Placket of lower pocket – 2 details
13. Belt – 1 detail

## **INSTRUCTIONS:**

1. Sew darts on front part. Press depths of darts downwards. Sew center edge of back part. Serge and press onto left side.
  2. Press lower seam allowance of pocket placket at 1 cm onto wrong side. Stitch unpressed edge of upper pocket placket to the pocket along side and lower edges, slashing the pocket in corners. Turn upper seam allowance of pocket twice inside onto wrong side and topstitch. Put pockets onto front part according to marking and topstitch. Fold flap details right sides together and overstretch. Slash seam allowances in flaps' corners and turn onto right side. Straighten and press seams. Put decorative stitch on the flap at 0.5 cm off the edge. Make buttonholes. Stitch flaps to front part, turn downwards and topstitch. Sew buttons on pockets according to buttonholes. Sew lower pockets the same way.
  3. Punch the eyelets according to marking.
  4. Sew shoulder seams. Press seams towards back part and serge. Put the stitch at 0.1 cm off the connecting seam.
  5. Sew sleeve into open armhole. Serge. Sew side edge and edge of sleeve. Serge and press the seam towards back part. Press hem onto wrong side first at 1 cm, then again at 2 cm.
  6. Turn long seam allowances of the belt inside and press. Put the belt onto the coat from the wrong side and topstitch at 0.1 cm off the fold.
  7. Serge inner edges of front bands. Turn seam allowance inside and topstitch.
  8. Sew outer collar into the neckline. Press seam allowance onto collar. Sew in zipper. **Please note:** zipper is stitched from top edge of collar up to the notch. Stitch front band to lower collar. Press seam allowances onto collar. Fold the band with outer collar right sides together and front band with lower collar right sided together. Overstretch front band, overstretching the collar at the same time. Lower edge of front band comes up to lower fold line. Turn onto right side and press. Turn seam allowance of inner collar inside and topstitch into outer collar connecting seam. Put decorative stitch along outer edge of collar and along zipper at 0.5 cm off the edge.
  9. Topstitch hem. Front band is between hem turnup and main detail. Press hem of sleeve at 1 cm onto wrong side, turn inside at 2 cm and topstitch.
  10. Fold the placket in half lengthwise and overstretch short sides. Turn placket onto right side, press and put decorative stitches along two short sides and along the fold at 0.5 cm off the edge. Stitch placket to front part, turn towards center and topstitch.
  11. Run the cord through eyelets, running it between the belt and the coat.
- ADVICE: ready cord can be used or one made from main fabric.

**TECHNICAL DRAWING:**

