

## Sewing Pattern — Jacket 5912

Recommendations on fabric: knitted fabric of low or middle stretchiness

You will also need: fusing, 3 buttons, cord for hood, two caps for cord

If the pattern has double contour the seam allowances are included.

If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out and cutting details.

Seam allowance: on hem of the garment – 4 cm, on hem of sleeve, hood edge and top edge of pocket – 2 cm, all other seams – 1cm.

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.

### **CUTTING:**

#### Main fabric:

1. Central back part - 2 details
2. Side back part - 2 details
3. Central front part - 2 details
4. Side front part - 2 details
5. Upper sleeve part – 2 details
6. Lower sleeve part – 2 details
7. Hood – 2 details
8. Buttonstand – 2 details
9. Pocket – 2 details

#### Fusing:

1. Buttonstand – 2 details

#### Attention:

Knitted fabric details of this model are sewn together with lockstitch machine. Topstitch hem allowances with double needle to save elasticity.



## **INSTRUCTIONS:**

1. Apply fusing to buttonstands.
2. Overstitch front stand edge and hem line with buttonstand. Sew seam from top point of front stand up to relief seam. Turn buttonstand onto right side and press. Sew relief edges on front part. Stitch hem allowance of side front part to buttonstand. Press seams to central part, serge and topstitch at 0.5-0.7 cm off the seam.
3. Sew relief edges on back part. Press seams to middle seam, serge and topstitch. Sew middle edge of back part. Press seam onto left side, serge and topstitch.
4. Sew shoulder and side seams. Press seams to back part and serge. Topstitch shoulder seams at 0.5-0.7 cm off the seam.
5. Mark and serge holes on hood, having applied fusing to them beforehand. Sew hood details. Press seam onto left side, serge and topstitch. Serge hood edge allowance, turn inside and topstitch. Sew the hood into the neckline. Slash seam near shoulder seam. Serge seam at level of back part neckline and topstitch onto the neckline. Serge shoulder edge of buttonstand. Overstitch the front part neckline with buttonstand.
6. Sew elbow edge of sleeve. Serge, press and topstitch onto top part of sleeve. Sew front sleeve seam. Serge and press to top part. Sew the sleeve in. Press seam towards sleeve and serge.
7. Serge hem of the garment, serging outer edge of buttonstand at the same time. Tack shoulder edge of buttonstand to shoulder seam. Press hem onto wrong side. Topstitch buttonstand and hem at 3.5 cm off the edge. Start and finish the seam near shoulder seam.
8. Serge upper edge of pocket, turn inside and topstitch. Press side and lower sides of pocket inwards. Mark pocket location on front part and topstitch the pocket.
9. Serge buttonholes on right front part sew buttons on left front part. Run the cord through the hood and fix caps.

## **TECHNICAL DRAWING:**

