

Sewing Pattern — Dress 5888

Recommendations on fabric: well-draping, light-weight natural/mixed fabric suitable for dresses

You will also need: lining; elastic thread

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam allowance: all seams - 1 cm, lower edges of back and of front – 0 cm, slanting and lower edges of the flounce - 0 cm

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold.

When sewing the garment, pay attention to notches, they must match up with corresponding pieces.



CUTTING:

(On the pattern pieces, “beam” means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.)

Main fabric:

1. Upper back - cut 1
2. Back – cut 2
3. Front – cut 2
3. Flounce - cut 2

Lining:

1. Upper back - cut 1
2. Back – cut 2
3. Front – cut 2

INSTRUCTIONS:

1. Cut the tie and loop from main fabric. The tie is 4 cm wide and 150 cm long, the loop is 4 cm wide, 4 cm long. Fold details in half lengthwise wrong sides together and press. Unfold, press side edges toward center, and fold in half. Topstitch at 0.1 cm from the edge.
2. Pin upper back with lining, right sides together, and sew long sides and top section, inserting the loop. Turn right side out, press.
3. Sew slanting and lower edges of the front flounce with narrow rolled hem. Sew front center seam, inserting flounces. Serge and press seam allowances onto left side.
4. Sew center back seam, serge and press seam toward left. Sew upper back to top edge of back.
5. Sew side seams, serge and press seam toward back.
6. Sew lining the same way as main fabric pieces. Pin lining to main garment, right sides together, and sew upper edge, leaving a 1 cm opening on vertical sides of front corners. Turn dress right side out and press. Form a casing for the tie by sewing 1 cm from the top seam, on front neck edge.
7. Serge lower edges of the dress and of lining (separately) with narrow rolled hem.
8. Sew, with elastic thread in the bobbin, along top edge of back, from side seam to upper back. Thread the tie through the casing and the loop.

TECHNICAL DRAWING:

