

Sewing Pattern — Jacket 5877

Recommendations on fabric: natural or mixed suiting fabrics

You will also need: lining; fusing; 1 button

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam allowance: all seams - 1 cm

Attention! First of all, please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to take into account pieces to be duplicated or cut on a fold.

When sewing the garment, pay attention to notches. They must match up with corresponding pieces.



CUTTING:

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Darts: The fold of the dart is always pressed toward the center of your garment, or down toward the hem.

Fabric:

1. Upper back— cut 2
2. Lower back – cut 2
3. Upper front – cut 2
4. Lower front – cut 4
5. Collar – cut 2
6. Upper sleeve – cut 2
7. Lower inner sleeve – cut 2
8. Lower outer sleeve – cut 2

Lining:

1. Upper back— cut 2
2. Upper front – cut 2
3. Upper sleeve – cut 2

Fusible interfacing:

1. Lower back – cut 1
2. Lower front – cut 2
3. Collar – cut 1

INSTRUCTIONS:

1. Apply interfacing to listed pieces.
2. Sew darts on back, press towards center. Sew center back seam, press seam toward left. Sew lower back to upper back, press seam onto lower back.
3. Sew lower front to upper front, clip into curves and press onto lower front.
4. Make a gathering stitch on upper and lower edges of lower outer sleeve and gather fullness. Pin lower outer and inner sleeves, right sides together, and sew along the lower edge. Turn right side out and press. Baste along top edge, having aligned the length. Pin main fabric pieces and lining pieces of upper sleeve, right sides together, insert lower part of sleeve between them and sew. Turn right side out and press. Then sew as one detail.
5. Sew sleeves to back and front, press seam allowances.
6. Sew side seams. Press seam allowances towards back.
7. Sew darts and center seam on lining back. Sew un-interfaced lower back to it. Sew interfaced lower front to lining of front. Sew side seams of lining, press seam allowances apart.
8. Pin lining onto main garment, right sides together, and sew lower edge of the left armhole. Clip into curves. Turn jacket onto right side, sew lining into sleeve connecting seam. Sew right armhole the same way.
9. Pin main garment with lining, right sides together, and sew edge of button-stand and lower edges of front and of back. Clip into curves, turn jacket onto right side. Fix lining to garment along neckline edge.
10. Pin collar right sides together and sew along outer edge. Start and finish the stitch exactly near marked line of collar connection. Clip into curves, turn collar onto right side.
11. Sew lower collar into the neckline. Clip into curves, and press seam onto collar. Turn seam allowance of outer collar under, and topstitch into connecting seam.
12. Make a buttonhole on right front, sew a button on left front.

TECHNICAL DRAWING:

