

## Sewing Pattern — Jacket 5839

Recommendations on fabric: lightweight natural / mixed woolen fabrics

You will also need: fusible interfacing; 2 hooks and 2 eyelets; lining; shoulder pads (for this jacket, raglan shoulder pads are recommended)

If the pattern has a double line around it, the seam allowances are included.

**Note:** By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam allowance: along the lower edge of the garment and lower edge of sleeve - 3.5 cm; along the lower edge of lining – 2 cm; all other seams – 1cm

Attention! First of all, please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to take into account pieces to be duplicated or cut on a fold.

When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

### **CUTTING:**

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Darts: The fold of the dart is always pressed toward the center of your garment, or down toward the hem.

#### **Main fabric:**

1. Center back– cut 2
2. Side back – cut 2
3. Side front – cut 2
4. Center front – cut 2
5. Front band facing – cut 2
6. Upper sleeve– cut 2
7. Lower sleeve – cut 2
8. Back neck facing – cut 1
9. Inset – cut 2



Lining:

1. Center front – cut 2
2. Center back – cut 2
3. Side back - cut 2
4. Side front – cut 2
5. Upper sleeve – cut 2
6. Lower sleeve – cut 2

\*NOTE: Lining is cut using main fabric patterns, excluding width of front band facing and back neck facing.

Fusible interfacing: Front band facing, back neck facing, upper center back along the armhole section, seam allowance along the lower edge of center back, side back armhole, seam allowance along the lower edge of side back, side front armhole, seam allowance along the lower edge of side front, center front armhole, seam allowance along the lower edge of lower sleeve, seam allowance along the lower edge of upper sleeve

**INSTRUCTIONS:**

1. Apply fusible interfacing to listed pieces.
2. Mark and sew darts on back. Press darts towards center. Sew side backs to center backs, press seams apart. Sew center back seam, press seam apart.
3. Make and sew up pleats on center front according to markers. Inner edges of 3 top pleats are turned towards side seam. Inner edges of 3 lower pleats are turned toward center front. Fix pleats near base-line. Sew inset to center front. Clip int curves, turn right side out and press. Do not press pleats. Sew side front to center fronts, press seams apart.
4. Sew hook and eyes to center front edge according to markers. Pin front band facing to front, right sides together, and sew along center front line. Sew from side of front upwards, leaving 5 cm to shoulder edges. Sew lower front band facing to center front exactly on hem marked line.
5. Sew shoulder and side seams of the jacket. Press shoulder and side seams apart.
6. Sew shoulder seams of back neck facing to front band facing and press seams apart.
7. Sew the neckline of the jacket with facing and understitch. Turn facing onto wrong side and press.
8. Sew and press apart elbow sleeve seam.
9. Sew and press apart front sleeve seam.
10. Make a gathering stitch along sleeve cap. Sew sleeves into armholes matching notches and adjusting ease. Sew in shoulder pads.
11. Sew lining same as main fabric, leaving a slit in front seam of right sleeve for turning. Press lining.
12. Sew lining to inner edges of facing and to hem of jacket, aligning seams of lining with the garment seams. Sew lining to sleeve hems. Make 7 bartacks along the edge of jacket above seams.
13. Turn jacket right side out through the slit in sleeve. Sew the slit in sleeve.

**TECHNICAL DRAWING:**

