

Sewing Pattern — Lingerie 5778

Recommendations on fabric: thin transparent fabric.

Seam allowances are NOT included and need to be added when laying out and cutting details.
Seam allowance 1 cm on all edges.

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.

CUTTING:

Fabric:

1. Back part – 2 details
2. Front part – 2 details
3. Sleeve – 2 details
4. Upper sleeve flounce – 2 details
5. Lower sleeve flounce – 2 details



INSTRUCTIONS:

1. Sew waist darts on back piece and bust darts on front piece. Press waist darts towards center and bust darts upwards.
2. Sew back central seam. Serge and press to the left.
3. Sew shoulder and side seams. Serge and press onto back piece.
4. Cut decorative detail from main fabric (width and length are given on front part detail). Sew all details together forming a ring, press apart and serge the seams. Overstitch one of the long sides with rolled seam, stitch loosely along the other edge and gather to match the required length (given on front piece detail).
5. Sew and serge sleeve seam.
6. Sew together upper and lower flounces, serge and press onto lower flounce. Sew flounce to sleeve hem (upper flounce is stitched into between the markers), press seam onto flounce and serge.
7. Cut decorative detail from main fabric (width and length are given on lower flounce detail). Sew all details together forming a ring, press apart and serge the seams. Overstitch one of the long sides with rolled seam, stitch loosely along the other edge and gather to match the required length (given on lower flounce detail). Sew decorative detail to sleeve hem, press seam onto flounce, serge and topstitch 0.1 cm off the seam.
8. Sew sleeves into armhole, easing them in along the cap. Serge the seam.
9. Cut ties from the main fabric, 10cm long and 4 cm wide. Fold the tie in half lengthwise, wrong sides together and press. Fold apart and press long edges towards center. Fold the tie along central line, put the folds together and topstitch 0.1 cm off the edge. Sew the ties to bottom part of front neckline into the seam of stitching decorative part to main detail.

TECHNICAL DRAWING:

