

Sewing Pattern — Nightdress 5777

Recommendations on fabric: natural/mixed silk

You will also need: bias tape (approximate length is mentioned on lower back part pattern).

If the pattern has double contour the seam allowances are included.

If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out and cutting details.

Seam allowances: all seams - 1 cm; top edge of upper back part and upper front part; armholes edges of back part and front part - 0 cm; along the lower edge of lower back part and lower front part – 4 cm

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



CUTTING:

Fabric:

1. Lower back part — 1 folded detail
2. Lower front part — 1 folded detail
3. Upper front part – 1 detail
4. Upper back part – 1 detail

INSTRUCTIONS:

1. Make a pleat on top part of the front between notches. Stitch loosely along the lower edge of upper front part between pleats by 0, 8 cm off the edge and gather ruffles according to given value. Stitch loosely along top edge of upper front part by 0, 8 cm off the edge and gather ruffles according to given value.
2. Stitch loosely along top edge of lower front part by 0, 8 cm off the edge and gather ruffles. Stitch upper front part to lower front part, press seam allowance upwards and serge.
3. Stitch loosely along top edge of lower back part by 0, 8 cm off the edge and gather ruffles. Stitch upper back part to lower back part, press seam allowance upwards and serge.
4. Press the bias tape in half lengthwise and pipe top edges of upper back part and upper front part. Overstitch armholes' edges, shaping straps.
5. Sew side seams. Press seam allowances towards back part and serge.

6. Press hem, turn inside first at 1 cm, then at 3 cm. Topstitch hem of the garment.
7. Topstitch bias tape onto connecting seam of upper and lower back/front parts.

TECHNICAL DRAWING:

