

Sewing Pattern — Blouse 5737

Recommendations on fabric: natural/mixed fabric

You will also need: fusing; 2 hooks and 2 loops

If the pattern has double contour the seam allowances are included.

Seam allowances are NOT included by default and need to be added when laying out and cutting details if your pattern has single contour.

Seam allowance: 4 cm for upper sleeve's hem, 0 cm for upper/lower frill, 1 cm for other seams

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



CUTTING:

Fabric:

1. Back part – 2 pieces
2. Front part – 1 piece
3. Sleeve – 2 pieces
4. Sleeve lining – 2 pieces
5. Stand-up collar – 1 piece
6. Lower frill – 1 piece
7. Upper frill – 1 piece

Fusing:

1. Stand-up collar – 1 piece

INSTRUCTIONS:

1. Apply the fusing to wrong side of stand-up collar.
2. Stitch back/front darts. Press darts toward center.
3. Stitch back middle edge between closure mark and the hem. Press seams apart, neaten them.
4. Stitch side/shoulder edges. Neaten side/shoulder seams. Press side/shoulder seams backward.

5. Fold the collar along the center right side out and overstitch it along short edges inserting hooks and loops. Turn the collar right side out and press it. Neaten frills along the perimeter. Coincide outer fill and inner frill as marked and make a seam with loose stitches along marked line. Make gathering to collar length. Copy from the pattern a line of frill joining. Topstitch frill on the outer collar. Make a seam with loose stitches along back/front neckline and gather fabric. Stitch the collar into the neckline coinciding notches. Press the seam.

6. Stitch seams into fabric/lining sleeves. Neaten the seam and press it. Make a seam with loose stitches along outer sleeve's hem and gather fabric a little. Lay outer sleeve on inner sleeve right sides together and stitch sleeves along hems. Neaten the seam and press it toward the lining. Turn details right side out, coincide them along sleeve caps and fix together with a stitch. After this, process the sleeve as one-layer detail. Make a seam with loose stitches between notches (upper notch on front part) and gather fabric a little. Stitch sleeves into armholes. Neaten the seam and press it front/backwards. Make a stitch along armholes at 0.1 cm from the seam.

7. Neaten the hem, fold it under and topstitch.

TECHNICAL DRAWING:

