

# **Sewing Pattern — Dress with Drapery 5533**

Recommendations on fabric: natural/mixed fabric.

You will also need: zipper, lining.

If the pattern has double contour the seam allowances are included.

Seam allowances are NOT included by default and need to be added when laying out and cutting details if your pattern has single contour.

Seam allowance: 1 cm for all seams, 2 cm for garment hem.

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



### **CUTTING**:

## Fabric:

- 1. Back part 2 pieces
- 2. Side part 2 pieces
- 3. Drapery 4 pieces
- 4. Front part 1 piece

#### <u>Lining:</u>

- 1. Back part 2 pieces
- 2. Side part 2 pieces
- 3. Front part 1 piece

#### **INSTRUCTIONS**:

Our advice: specify drapery during fitting.

- 1. Stitch side darts, press them backwards.
- 2. Neaten lower/upper edges of drapery. Press upper edge of drapery into wrong side at 0.5 cm from edge. stitch lower edge of drapery to notch, press joining seam apart pressing slits. Make decorative stitch along slits at 0.5 cm from edge. Make pleats into drapery yourself or by ready draped fabric. Specify the drapery according to pattern and interlace the drapery according to technical sketch; tack the drapery to front relief edge.
- 3. Neaten front/back relieve seams, stitch them and press apart; leave a slit into d\font left relieve seam.



- 4. Neaten middle back edge. Stitch middle seam up to closure notch, press the seam apart pressing closure slits. Stitch the zipper in.
- 5. Stitch lining detail leaving a slit into font left relief seam. Neaten lining seams and press front seams towards front center and back seams press towards back center. Neaten lining middle edge. Neaten lining hem, fold it under and topstitch.
- 6. Cut shoulder straps. Fold shoulder straps along the center wrong side out and make a stitch at 0.5 cm from fold. Turn straps tight side out and press them. Sew straps to front neckline.
- 7. try the dress, adjust strap length and sew back seams on back part.
- 8. Tack drapery to edge of front armhole and process the draping. Overstitch front/back neckline, armhole and a slit into relieve seam with the lining. Topstitch overstitching allowance on the lining at 0.2 cm from overstitching. Remove tacking. Fold lining's middle edge under and stitch it to dress allowance at closure segment. Make decorative stitch along the slit at 0.5 cm from edge.
- 9. Neaten dress hem, fold it under and topstitch at 1.5 cm from lower edge.

## **TECHNICAL DRAWING:**

