

Sewing Pattern — Jacket 4218

Recommendations on fabric: thin costume fabric of natural or mixed fibers.

You will also need: fusing; lining; 4 buttons; shoulder pads; sleeve heads.

If the pattern has double contour the seam allowances are included.

Seam allowances are NOT included by default and need to be added when laying out and cutting details if your pattern has single contour.

Seam allowance: all seams - 1 cm; on hem of sleeve and hem of the garment - 3.5 cm .

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



CUTTING:

Fabric:

1. Central back part – 2 details
2. Side back part – 2 details
3. Side front part – 2 details
4. Central front part – 2 details
5. Collar - 2 details
6. Buttonstand – 2 details
7. Back neckline facing – 1 detail
8. Upper sleeve part – 2 details
9. Lower sleeve part – 2 details
10. Off-set welt - 2 details
11. Underlay piece - 2 details

Lining:

1. Central front part – 2 details
2. Side front part - 2 details
3. Central back part – 2 details
4. Side back part – 2 details
5. Upper sleeve part – 2 details
6. Lower sleeve part – 2 details

One-piece back part and front part lining details are cut except for the width of facings neckline and buttonstands facings correspondingly.

Fusing: central front part, buttonstand, back part neckline facing, top collar, off-set welt, hem of sleeve and hem of jacket.

INSTRUCTIONS:

1. Apply fusing to details .
2. Sew and press darts on back part towards center. Sew and press apart relieve seams of back part. Sew and press apart middle seam of back part.
3. Fold off-set welt detail in half lengthwise right sides together and overstretch ends. Slash seam allowances in corners and turn off-set welt the right side out. Straighten and press the seams.
4. Sew dart on front part and slash the depth away. Press bust dart apart. Fix pocket opening with stitched bias tape from fusing or tack. Sew and press apart relieve seams on front part, press seam allowances apart.
5. Mark pocket location. Mark additional lines on off-set welt and pocket underlay piece for connection. Mark additional lines parallel to pocket opening. Stitch underlay piece and off-set welt to front part. End stitches near parallel lines of pockets marking. Check if you connected correctly from wrong side (stitches must be parallel). Cut pocket opening. Make cross slashes at 1-1, 5 cm off pocket end. Turn underlay piece and off-set welt through given slit onto wrong side, straighten edge. Fix ends of pocket from wrong side with double back stitch on corners base. Topstitch ends of off-set welt on front part, topstitch off-set welt into connecting seam onto underlay piece.
6. Sew and press apart shoulder and side edges of jacket.
7. Fold details of collar right sides together and overstretch left side and outer edge up to center. Start the stitch exactly near marked line of collar connecting seam. Slash seam allowances in corners, slash on rounded parts. Turn collar out, straighten and press.
8. Sew and press apart shoulder edges of back part and buttonstands neckline facing.
9. Fold left buttonstand with front part right sides together and overstretch left buttonstand and neckline edge up to marker. Topstitch buttonstand seam allowance onto buttonstand from hem up to neckline. Stitch by 0, 2 cm off the seam. Slash seam allowance on neckline near marker. Turn buttonstand onto right side, straighten seams. Sew top collar into the neckline of back part and of front part. Press apart the seam. Sew lower collar into the facing and buttonstand neckline. Press apart the seam.
10. Fold right buttonstand with front part right sides together and overstretch right buttonstand and collar. Topstitch buttonstand seam allowance from hem up to buttonstandneckline. Stitch by 0, 2 cm off the seam. Turn buttonstand and collar onto right side, straighten, press. Put fixing stitch along the seam of collar and neckline connection.
11. Sew and press apart elbow sleeve seam. Press hem of sleeve. Sew and press apart front sleeve seam.
12. Sew sleeves into armholes according to notches, gathering slightly on rounded parts. Sew in shoulder pads and sleeve heads.
13. Sew seams on lining details and sew in sleeves, leaving a slit in front right seam of sleeve.
14. Stitch lining to inner buttonstand edges and back part neckline facing. Press allowances of collar connecting seams apart and fix close to seams.
15. Stitch lining to jacket hem and sleeve hem. Turn jacket through the slit in sleeve. Sew slit in sleeve.
16. Serge buttonholes on right front part, sew buttons on left front part.

TECHNICAL DRAWING:

