

Sewing Pattern — Jacket 5321

Recommendations on fabric: artificial leather or suede

You will also need: fusing; separable zipper; lining

If the pattern has double contour the seam allowances are included.

If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out and cutting details.

Seam allowance : 1 cm for all seams

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



CUTTING:

Fabric:

1. Inner collar – 1 detail
2. Outer collar – 1 detail
3. Center back part – 2 details
4. Side back part – 2 details
5. Back yoke – 1 detail
6. Front yoke – 2 details
7. Side front part – 2 details
8. Center front part – 2 details
9. Front band – 2 details
10. Upper sleeve – 2 details
11. Lower sleeve – 2 details

Lining:

1. Center back part – 1 detail
2. Side back part - 2 details
3. Side front part – 2 details
4. Center front part – 2 details
5. Upper sleeve – 2 details
6. Lower sleeve – 2 details

Fusing: front band, inner collar; hem allowance: center back part, side back part, lower sleeve, side front part, upper sleeve.

INSTRUCTIONS:

1. Strengthen the front band, inner collar; hem allowance: center back part, side front part, side back part, lower sleeve, upper sleeve with clue interfacing.
2. Overstitch inner collar with outer one (right sides together). Cut, then turn the collar right side out.
3. Sew front/back relieves. Make decorative stitch on 0.5 cm distance of relieves joining seam.
4. Sew yokes to front part and back part. Make decorative stitch on 0.5 cm distance of yoke joining seam.
5. Fold front parts right sides together, then adjust edges coinciding yokes, then measure front band lengths. Sew zipper to edges. Fold front band edge under at zipper area, then press through the pressing cloth.
6. Fold the front band and front part right sides together, then overstitch along the edge from the front part side. Sew front bands lower edges to front part strictly along marked hemline. Cut upper and lower seams corners. Turn edges right side out, trim seams. Make decorative stitch on 0.5 cm from the edge.
7. Sew shoulder and side seams.
8. Sew the inner collar to the neckline. Sew outer collar to front band.
9. Sew sleeve elbow seam. Sew sleeve front seam. Press sleeve hem allowance under.
10. Sew the sleeves into the armholes according to notches. Sew shoulder pads and sleeve heads.
11. Sew lignin details seams, sew sleeves into, with the hole in sleeve right seam unsewn. Sew the lining to front band inner edges and outer collar. Fix collar joining seam allowances near seams.
12. Sew lining to inner cuff lower edge and jacket hem. Turn the jacket right side out through the hole in the sleeve. Sew the hole.

TECHNICAL DRAWING: