

## Sewing Pattern — Top 5288

Recommendations on fabric: elastic cotton, natural or artificial knitted fabric.

You will also need: clue interfacing; braid of 0.5 cm width, eyelets.

If the pattern has double contour the seam allowances are included.

If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out and cutting details.

SEAM ALLOWANCE: 1 cm for all seams.

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



### **CUTTING:**

#### Fabric:

1. Front center - 2 details
2. Front side – 2 details
3. Back center - 1 detail
4. Back side – 2 details
5. Front band - 2 details
6. Back neckline facing – 1 detail
7. Sleeve - 2 details

Clue interfacing: front band, back neckline facing.

**OUR ADVICE:** To make the fabric along stitched seams stretch, sew details with narrow zigzag or with special stretchable stitches. To make the hem stretch, oversew hem allowance with special oversewstitches (overlock), and then sew it using double needle. This is also attachable to other edges that should stay elastic.

These recommendations are not for industry.

### **INSTRUCTIONS:**

1. Strengthen the front band and back neckline facing with clue interfacing.
2. Sew front part relieves.

3. Sew back part relieves.
4. Sew neckline facing to front bands.
5. Oversew front band outer edge and the facing.
6. Sew shoulder seams.
7. Sew side seams.
8. Overstitch front bands and back neckline with front bands (with facing), then turn front bands into wrong side. Oversew and pressed edges. Sew front bands on shoulder seams with stitch of 1 cm width.
9. Sew sleeve seams to the notch, with unsewn vent. Press sleeve hem allowance into right side. Sew vent edges. Press hem allowance into wrong side and topstitch.
10. Sew sleeves into arm holes fitting them along caps.
11. Press garment hem allowance into wrong side and topstitch into the edge.
12. Make string eyelets.

**TECHNICAL DRAWING:**

