

Sewing Pattern — Blouse 4204

Recommendations on fabric: waterproof fabric

You will also need: lining; warmer (sintepon, isosoft), separable zipper (length is shown on front part pattern), elastic for closure of 1.5 – 2 cm wide, elastic tape for piping.

If the pattern has double contour the seam allowances are included.

If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out and cutting details.

Seam allowance: on edges of lining – 1 cm; on edges of the armhole, pocket opening edge, hood edge and along the edge of the garment – 0 cm, all other seams – 1.5 cm.

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



CUTTING:

Main fabric:

1. Back yoke - 1 detail
2. Back part - 1 detail
3. Front part yoke - 2 details
4. Front part - 2 details
5. Central part of hood - 1 detail
6. Side part of hood - 2 details
7. Back neckline facing – 1 detail
8. Front stand – 2 details
9. Inner panel — 2 details
10. Bigger pocket bag - 2 details

Lining:

1. Front part – 2 details
2. Back part – 1 detail
3. Central part of hood - 1 detail
4. Side part of hood - 2 details
5. Smaller pocket bag – 2 details

Warmer:

1. Back yoke - 1 detail
2. Back part - 1 detail
3. Front part yoke - 2 details
4. Front part - 2 details
5. Central part of hood - 1 detail
6. Side part of hood - 2 details
7. Inner panel — 1 detail
8. Bigger pocket bag – 2 details

Note: 1). Hood lining is cut according to main fabric patterns.
2). Warmer is cut according to main fabric patterns.
3). Before sewing check fabric is steaming-care.

INSTRUCTIONS:

1. Topstitch yokes, details of back part, front part, pocket bags and hood onto corresponding warmer details. Topstitch panel onto warmer. Overstitch inner panel along short and one long sides. Turn details out, press and stitch-out at 0.7 cm off the seam.
2. Topstitch elastic onto wrong side of back part and front part according to markers, slightly stretching it (length of elastic is mentioned on patterns).
3. Stitch loosely on top edge of front part and gather ruffles. Stitch yoke to front part. Press seam upwards. Stitch loosely on top edge of back part and gather ruffles. Stitch yoke to back part. Press seam upwards.
4. Fold smaller pocket bag with front part wrong sides together and pipe pocket opening with elastic tape. Stitch bigger pocket bag to relieve edge of back part. Sew pocket bags together. Sew relieve edge of front part and of back part. Press seam towards center of front part.
5. Sew shoulder seams, press seam allowances apart.
6. Sew hood details. Press seam to middle part and stitch-out on 0.7 cm. Sew the hood into the neckline. Press the seam.
7. Cut 2 bias tapes from main fabric of 3.2 cm wide and as long as front stand (including hood) + 4 cm. Press longitudinal edges on 1 cm inwards. Put tape wrong side onto right side of front part. Turn outer edge away and level it to front stand edge. Leave 2 cm from above and from below. Fix tape to front part on 0.5 cm from front stand edge.
8. Topstitch right half of zipper onto inner panel, leveling zipper tape edge to open edge of the panel. Stitch panel with zipper to right front stand. Stitch left half of zipper to left front part.
9. Lining: Sew back part lining details, details of front part and hood separately. Sew shoulder and relieve edges. Sew and press apart shoulder edge of back part neckline facing and front stand. Stitch lining to front stands and facing. Sew the hood into the neckline.
10. Overstitch front stand edge with lining. Fix together seam allowances of the hood connecting seam on main fabric details and on lining details. Fix hood to lining along hood edge, slightly gathering the edge. Overstitch hood edge with bias tape.
11. Fix main garment and lining along armhole, slightly gathering the edge and leveling edges of main garment and lining. Measure bias tape length equal to the armhole length + 2 cm. Sew the bias tape into ring. Overstitch edge of the armhole.
12. Fix main garment and lining along the edge of the garment, slightly gathering the edge and leveling edges of main garment and lining. Overstitch lower edge.
13. Topstitch tape along front stand, turning top and lower ends inside.

TECHNICAL DRAWING:

