

## Jacket With Low Waist - Sewing Pattern #2073

Recommendations on fabric: natural/mixed suiting fabric.

You will also need: fusible interfacing; lining; 4 buttons; shoulder pads, sleeve heads.

Seam allowances: all seams 1 cm. Seam allowance on lower edge of sleeve – 3 cm.

### Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

### Note on length of fabric:

*Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.*



## CUTTING:

### Note on cutting:

*On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.*

*When sewing the garment, pay attention to notches, they must match up.*

Main fabric:

1. Center back – cut 2
2. Side back – cut 2
3. Lower back – cut 1
4. Center front – cut 2
5. Side front – cut 2
6. Lower front – cut 2
7. Upper sleeve – cut 2

8. Lower sleeve – cut 2
9. Back neck facing – cut 1
10. Upper part center front facings – cut 2
11. Lower part center front facings – cut 2
12. Collar – cut 2
13. Pocket welt – cut 2

Lining:

1. Center back – cut 2
2. Center front – cut 2
3. Side back – cut 2
4. Side front – cut 2
5. Upper sleeve – cut 2
6. Lower sleeve – cut 2
7. Lower front – cut 2
8. Lower back – cut 1
9. Large pocket bag – cut 2
10. Small pocket bag – cut 2

Fusible interfacing: center front, back neck facing, upper part center front facings, lower part center front facings, upper collar.

Attention: lining is cut using pattern blocks for self fabric except for the area of center front facing and back neckline facing.

## INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew side backs to center back. Press towards center. Sew a decorative stitch at 0.5 cm from seam. Sew center back seam. Press the seam apart. Sew lower back to garment. Press the seam allowances apart.
3. Mark the position of pocket. Press welt in half lengthwise wrong sides together. Topstitch small pocket bag onto inner side of welt. Sew welt to front along lower marked line of pocket. Sew large pocket bag to front along upper marked line of pocket. Stop stitching near short marking lines of the pocket. Slash through pocket opening. Snip diagonally toward end of stitching at 1-1.5 cm from end of pocket opening. Turn welt and large pocket bag onto wrong side through the resulting opening. Sew a double back stitch lines near corners to fix ends of pockets. Sew together edges of pocket bags.
4. Sew side fronts to center front. Press towards center. Sew a decorative stitch at 0.5 cm along the seam. Sew lower front in two steps: from center front edge to loop mark, and from loop mark to side edge. Press the seam allowances apart.

5. Pin upper collar to lower collar and sew the corners and the outer edge. Trim away corners. Turn the collar right side out, straighten and press. Sew a decorative stitch along the collar at 0.5 cm from the edge. Sew collar into neckline.
6. Sew and press apart shoulder and side edges of jacket.
7. Sew and press elbow seam apart. Sew and press apart front sleeve seam. Press seam allowance of the lower edge of garment inside. Sew sleeves into armholes matching notches. Sew shoulder pads, sew sleeve heads.
8. Sew together center front facings in two steps: first sew from center front edge to loop mark, and then from the loop mark to inner edge. Press the seam apart.
9. Sew and press apart the shoulder edges of the back neckline facing and of the center front facing.
10. Sew seams on lining and sew in sleeves, leaving an opening for turning in front right sleeve seam. Sew lining to the central front facings and to facing.
11. Place center front facing onto front right sides together, pin together and sew along center front, along lower edge, and along neckline. Sew lining to hem of sleeve. Turn jacket right side out through the opening. Baste together seam allowances of the front and center front facings, forming a loop. Baste together the seam allowances of waist seams. Sew the opening in sleeve closed.
12. Make buttonholes on right front, and sew on buttons onto left front.

## **TECHNICAL DRAWING:**

