

## Denim Jacket - Sewing Pattern #2089

Recommendations on fabric: natural/mixed jeans fabrics, denim.

You will also need: fusible interfacing; lining; 3 buttons.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment and hem of sleeve - 2.5 cm. Seam allowance along short edges of casing - 2 cm.

### Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

### Note on length of fabric:

*Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.*



## CUTTING:

### Note on cutting:

*On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.*

*When sewing the garment, pay attention to notches, they must match up.*

Main fabric:

1. Center back - cut 2
2. Side back - cut 2
3. Back yoke - cut 1
4. Center front - cut 2
5. Side front - cut 2
6. Front yoke - cut 2
7. Lower collar - cut 1

8. Upper collar - cut 1
9. Center front facing - cut 2
10. Back neck facing - cut 1
11. Sleeve - cut 2
12. Casing - cut 1
13. Flap - cut 4
14. Pocket frame - cut 2
15. Belt - cut 1

Lining:

1. Smaller pocket bag - cut 2
2. Bigger pocket bag - cut 2

Fusible interfacing:

1. Center front facing - cut 2
2. Back neck facing - cut 1
3. Upper collar - cut 1
4. Flap - cut 2
5. Pocket frame - cut 2
6. Belt - cut 1

## **INSTRUCTIONS:**

1. Apply fusible interfacing. Apply fusing on front along the lapel fold , its width should equal 1 cm (fusible interfacing).
2. Sew the center back seam, serge and press towards left. Sew back yoke to yoke. Serge the seam allowances and press onto yoke. Sew a decorative stitch at 0.5 cm from seam. Sew side backs to center back. Serge seams and press towards center. Sew a decorative stitch at 0.5 cm from seam.
3. Sew yoke to front. Serge the seam allowances and press onto yoke. Sew a decorative stitch at 0.5 cm from seam. Sew side front to center front. Serge seams and press towards center. Sew a decorative stitch at 0.5 cm from seam.
4. Sew flaps together by two, right sides together and sew along side and lower edges. Trim seam allowances, snip into curves, turn right side out and press. Mark the position of pockets with parallel lines. Fold pocket frame in half, wrong side together and press. Mark additional lines on pocket frame and on pocket flap for sewing it parallel to the fold. Sew bigger pocket bag to pocket flap. Sew pocket frame and pocket flap to front. Slash front along the line as marked on the pattern block. Snip diagonally toward end of stitching at 1-1.5 cm from end of pocket opening. Turn the pocket frame and the pocket flap onto wrong side through the resulting opening, straighten edges. Fix corners of pockets in place by stitching a double stitch line from the wrong sides at the corners. Sew smaller pocket bag into the seam of pocket frame. Sew together edges of pocket bags, serge.

5. Sew shoulder and side seams. Serge seams and press towards back.
6. Turn under short edges of casing two times by 1 cm and topstitch. Turn under seam allowances along longer edges, and topstitch the casing onto jacket along the marked lines.
7. Pin upper collar to lower collar and sew the corners and the outer edge. Start and stop sewing exactly at the marked line of the seam between collar and garment. Clip into curves, snip into seam allowance near the mark. Turn the collar right side out, straighten and press.
8. Sew and press apart the shoulder edges of the back neckline facing and of the center front facing.
9. Place center front facing onto front right sides together, pin together and sew along the center front edge. Sew upwards up to the notch marking the end of collar seam.
10. Sew lower collar into neckline of Shell, sew upper collar into back neckline facing and center front facing. Press seam allowances of the collar seam apart and slipstitch them together close to the seam.
11. Sew sleeve seam, press towards back part. Sew sleeves into armholes matching notches, adjusting ease along upper side of sleeve cap.
12. Hem of sleeve and of jacket serge, turn inside and topstitch. Sew a decorative stitch along center front edge and collar at 0.5 cm from the edge.
13. Make buttonholes and sew on buttons.
14. Fold belt in half lengthwise right sides together and sew around all edges, leaving an opening for turning. Trim away corners, turn the piece right side out, press. Sew the opening closed. Thread belt into casing.

## **TECHNICAL DRAWING:**

